Original	Replacement	Original	Replacement
Power	Power	Sleep	Sleep / Timer
CBL/SAT	Shift + 0	Volume+	Vol +
DVD	Shift + 2	CH/Page-	CH- / Page-
TV Audio	Shift + 1	Eco	D.Menu / Top
Blu-ray	Shift + 4	Mute	Mute / Dimmer
AUX1	Shift + 7	Volume-	Vol -
Tuner	Shift + 6	Info	Info / Angle
Bluetooth	Shift + 9	Up	Up
Game	Shift + Fav / Marker / PC	Option	Shift + Setup / OPT / Tools
AUX2	Shift + Guide / EPG / -/--	Left	Left
Phono	Shift + 5	Right	Right
iPod / USB	Shift + 8	Back	Back / Return
Media Player	Display / Media	Down	Down
CD	Shift + 3	Setup	Setup / OPT /
Online Music	Smart / List	Home	Menu / Home
Internet Radio	Shift + Smart / List	Stop	Stop / Hold
CH/Page+	CH+ / Page+	Pause	Pause / Step / Freeze

Original	Replacement	Original	Replacement
Play	Play / Slow	3	3
I <</ Tune-	I << / Preset-	4	4
I <</ Tune-	Shift + << /	5	5
>>I / Tune+	>>I / Preset+	6	6
>>I / Tune+	Shift + >> /	7	7
<<	<< / Tune-	8	8
>>	>> / Tune+	9	9
Smart Select 1	Sound / Title	0	0
Smart Select 2	Audio / Lang I/II	Enter	OK
Smart Select 3	Subtitle / EQ		
Smart Select 4	Eject / Surround		
Green/ Movie	Green / APP / Repeat		
Red/ Music	Red / Netflix / Search		
Blue/ Game	Blue / Prime Video / Random		
Yellow/ Pure	Yellow / YouTube / Repeat		
1	1		
2	2		

Original	Replacement
Power	Power
CBL/SAT	Shift + 0
DVD	Shift + 2
TV Audio	Shift + 1
Blu-ray	Shift + 4
AUX1	Shift + 7
Tuner	Shift + 6
Bluetooth	Shift + 9
Game	Shift + Fav / Marker / PC
AUX2	Shift + Guide / EPG / -/--
Phono	Shift + 5
iPod / USB	Shift + 8
Media Player	Display / Media
CD	Shift + 3
Online Music	Smart / List
Internet Radio	Shift + Smart / List
CH/Page+	CH+ / Page+

Original	Replacement
Sleep	Sleep / Timer
Volume+	Vol +
CH/Page-	CH- / Page-
Mute	Mute / Dimmer
Volume-	Vol -
Up	Up
Left	Left
Right	Right
Back	Back / Return
Down	Down
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
I<</Tune-	Shift + << /
I<</Tune-	I<< / Preset-
>>I/Tune+	Shift + >> / Tune+

Original	Replacement	Original	Replacement
>>I / Tune+	>>I / Preset+	Enter	OK
<<	<< / Tune-		
>>	>> / Tune+		
Smart Select 1	Sound / Title		
Smart Select 2	Audio / Lang I/II		
Smart Select 3	Subtitle / EQ		
Smart Select 4	Eject / Surround		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		

Original	Replacement
Power	Power
CBL/SAT	Shift + 0
DVD	Shift + 2
TV Audio	Shift + 1
Blu-ray	Shift + 4
AUX1	Shift + 7
Tuner	Shift + 6
Bluetooth	Shift + 9
Game	Shift + Fav / Marker / PC
AUX2	Shift + Guide / EPG / -/--
Phono	Shift + 5
iPod / USB	Shift + 8
Media Player	Display / Media
CD	Shift + 3
Online Music	Smart / List
Internet Radio	Shift + Smart / List
CH/Page+	CH+ / Page+

Original	Replacement
Sleep	Sleep / Timer
Volume+	Vol +
CH/Page-	CH- / Page-
Mute	Mute / Dimmer
Volume-	Vol -
Up	Up
Left	Left
Right	Right
Back	Back / Return
Down	Down
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
I<</Tune-	Shift + << /
I<</Tune-	I<< / Preset-
>>I/Tune+	Shift + >> / Tune+

Original	Replacement	Original	Replacement
>>I / Tune+	>>I / Preset+	Enter	OK
<<	<< / Tune-		
>>	>> / Tune+		
Smart Select 1	Sound / Title		
Smart Select 2	Audio / Lang I/II		
Smart Select 3	Subtitle / EQ		
Smart Select 4	Eject / Surround		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		