Mandis shop

WL-D88

Original		Replacement	
START/ STOP	Start/Stop		Power
PHOTO	Photo	HOME SMART	Smart
ZOOM T	Zoom T	CH +	Ch +
W	Zoom W	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
FUNC.	Func.	SETTINGS OPT	Options
PLAYLIST	Play List	DISC NAV LIST	List
	Up		Up
	Down		Down
	Right		Right
	Left		Left
SET	Set	OK	Ok
II>	II>	>>I	>>I
<II	<II	I<<	I<<
>>	>>	>>	>>
<<	<<	<<	<<
	Play	PLAY MODE	Play

Original		Replacement	
II	Pause	II	Pause
	Stop	■	Stop
DISP.	Disp.	DISPLAY INFO	Info

https://all-remote-controls.nl/en/Canon/1064036-93593-replacement-remote-control-for-Canon-WL-D88.html