Original	Replacement	Original	Replacement
Power Source	SHIFT + Power	Audio 2	SHIFT + DVD 2 (Shift + 2)
Power Receiver	Power	Tuner	SHIFT + TUNER 6 (Shift + 6)
HDMI 1	NETFLIX SEARCH (Red / Netflix / Search)	USB	SHIFT + USB 8 (Shift + 8)
HDMI 2	APP REPEAT (Green / APP / Repeat)	Net	SHIFT + VIDEO 4 (Shift + 4)
HDMI 3	YouTube REPEAT A-B (Yellow / YouTube / Repeat)	Phono	SHIFT + CD-STB 3 (Shift + 3)
HDMI 4	Prime Video RANDOM (Blue / Prime Video / Random)	Party	PROGRAM TV/RADIO (TV/Radio /
HDMI 5	SHIFT + TAPE 5 (Shift + 5)	HDMI Out	RDS AV INPUT (AV / Input / RDS
HDMI 6	SHIFT + HDMI-SAT 0 (Shift + 0)	BD/DVD Scene	SHIFT + ▲ (Shift + Up)
HDMI 7	SHIFT + BLUETOOTH 9 (Shift + 9)	TV Scene	SHIFT + ◀ (Shift + Left)
V-AUX	SHIFT + AUX-HDD 7 (Shift + 7)	NET Scene	SHIFT + ▶ (Shift + Right)
AV 1	SHIFT + NETFLIX SEARCH (Shift + Red / Netflix /	Radio Scene	SHIFT + ▼ (Shift + Down)
AV 2	SHIFT + APP REPEAT (Shift + Green / APP /	Program Up	CH+ / Page+
AV 3	SHIFT + YouTube REPEAT A-B (Shift + Yellow / YouTube /	Volume+	Vol +
AV 4	SHIFT + Prime Video RANDOM (Shift + Blue / Prime	Program Down	CH- / Page-
AV 5	SHIFT + GUIDE EPG (Shift + Guide / EPG / -/--)	Mute	DIMMER MUTE (Mute / Dimmer
AV 6	SHIFT + PC FAV MARKER (Shift + Fav / Marker / PC)	Volume-	Vol -
Audio 1	SHIFT + TV 1 (Shift + 1)	Top Menu	TOP MENU D.MENU (D.Menu / Top Menu)

Original	Replacement	Original	Replacement
Pop-Up Menu	Menu / Home	Preset >>I	>>I / Preset+
On Screen	Text / Goto	Movie	Sound / Title
Up	Up	Music	Audio / Lang I/II
Option	Setup / OPT /	Sur. Decode	Eject / Surround
Left	Left	Straight	Picture / Format
Enter	OK	Info	Info / Angle
Right	Right	Sleep	Sleep / Timer
Return	Back / Return	Enhancer	Subtitle / EQ
Down	Down	Pure Direct	Zoom / Size
Display	Display / Media	1	1
Mode	Smart / List	2	2
Stop	Stop / Hold	3	3
Pause	Pause / Step / Freeze	4	4
Play/Band	Play / Slow	5	5
<< Tuning	<< / Tune-	6	6
Tuning >>	>> / Tune+	7	7
I << Preset	I << / Preset-	8	8

Original		Replacement		Original	Replacement
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
MEMORY +10	+10/ Memory	-/-- GUIDE EPG	Guide / EPG / -/--		
ENT.	ENT.	PC FAV MARKER	Fav / Marker / PC		

Original	Replacement	Original	Replacement
Power Source	SHIFT + Power	Audio 2	SHIFT + DVD 2 (Shift + 2)
Power Receiver	Power	Tuner	SHIFT + TUNER 6 (Shift + 6)
HDMI 1	NETFLIX SEARCH (Red / Netflix / Search)	USB	SHIFT + USB 8 (Shift + 8)
HDMI 2	APP REPEAT (Green / APP / Repeat)	NET	SHIFT + VIDEO 4 (Shift + 4)
HDMI 3	YouTube REPEAT A-B (Yellow / YouTube / Repeat)	Phono	SHIFT + CD-STB 3 (Shift + 3)
HDMI 4	Prime Video RANDOM (Blue / Prime Video / Random)	Party	PROGRAM TV/RADIO (TV/Radio /)
HDMI 5	SHIFT + TAPE 5 (Shift + 5)	HDMI Out	RDS AV INPUT (AV / Input / RDS)
HDMI 6	SHIFT + HDMI-SAT 0 (Shift + 0)	BD/DVD Scene	SHIFT + ▲ (Shift + Up)
HDMI 7	SHIFT + BLUETOOTH 9 (Shift + 9)	TV Scene	SHIFT + ◀ (Shift + Left)
V-AUX	SHIFT + AUX-HDD 7 (Shift + 7)	NET Scene	SHIFT + ▶ (Shift + Right)
AV 1	SHIFT + NETFLIX SEARCH (Shift + Red / Netflix /)	Radio Scene	SHIFT + ▼ (Shift + Down)
AV 2	SHIFT + APP REPEAT (Shift + Green / APP /)	Volume+	VOL + (Vol +)
AV 3	SHIFT + YouTube REPEAT A-B (Shift + Yellow / YouTube /)	Mute	DIMMER MUTE (Mute / Dimmer)
AV 4	SHIFT + Prime Video RANDOM (Shift + Blue / Prime)	Volume-	VOL − (Vol -)
AV 5	SHIFT + GUIDE EPG (Shift + Guide / EPG / -/--)	Top Menu	TOP MENU D.MENU (D.Menu / Top)
AV 6	SHIFT + PC FAV MARKER (Shift + Fav / Marker / PC)	Pop-Up Menu	HOME MENU (Menu / Home)
Audio 1	SHIFT + TV 1 (Shift + 1)	On Screen	GOTO TEXT (Text / Goto)

Original		Replacement	
	Up		Up
	Option	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
	Enter	OK	OK
	Right		Right
	Return	RETURN BACK	Back / Return
	Down		Down
	Display	MEDIA DISPLAY	Display / Media
	Mode	LIST SMART	Smart / List
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play/Band	SLOW	Play / Slow
	<< Tuning	TUNE-	<< / Tune-
	Tuning >>	TUNE+	>> / Tune+
	I<< Preset	PRESET-	I<< / Preset-
	Preset >>I	PRESET+	>>I / Preset+
	Info	ANGLE INFO	Info / Angle

Original		Replacement	
	Sleep	TIMER SLEEP	Sleep / Timer
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI-SAT 0	0
	+10/Memory	-/-- GUIDE EPG	Guide / EPG / -/--
	ENT	PC FAV MARKER	Fav / Marker / PC