Mandis shop

Yamaha RAS15

Original	Replacement
Power AMP	Power
Power CD	Shift + Power
Open/Close	Eject
CD Direct AMP	Smart
Pure Direct	Media
CD	1
Coaxial	2
Optical	3
Line 1	4
Line 2	5
Line 3	6
Tuner	7
Phono	8
USB	9
Band	TV/R
Tuning >>	Right
<< Tuning	Left

Original	Replacement
Preset >	Ch +
< Preset	Ch -
Memory	Ok
<<	<<
>>	>>
>>I	>>I
I <<	I <<
Pause	Pause
Play	Play
Stop	Stop
Volume+	Vol +
Volume-	Vol -
Mute	Mute

https://al-remotecontrols.nl/en/Yamaha/1643863/replacement-remote-control-for-Yamaha-RAS15.html