Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/ SAT	TV 1	1
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	TAPE 5	5
GAME	Game	VIDEO 4	4
MEDIA PLAYER	Media Player	HDMI - SAT 0	0
CD	CD	CD - STB 3	3
PHONO	Phono	AUX - HDD 7	7
TV AUDIO	Tv/ Audio	-/-- GUIDE EPG	Guide / EPG / -/--
TUNER	Tuner	TUNER 6	6
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	PC FAV MARKER	Fav / Marker / PC
	.:I:.	LIST SMART	Smart / List
CH/PAGE	CH/ Page+	+ CH PAGE	CH+ / Page+
CH/PAGE	CH/ Page-	CH PAGE –	CH- / Page-
ECO	Eco	MEDIA DISPLAY	Display / Media

Original		Replacement	
VOLUME	Volume+	+ VOL	Vol +
VOLUME	Volume-	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
INFO	Info	ANGLE INFO	Info / Angle
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
BACK	Back	RETURN BACK	Back / Return
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	OK
►/II	Play	SLOW ►	Play / Slow
TUNE –	I <</ Tune-	PRESET-	I << / Preset-
►/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+
BAND	<</ Band	TUNE-	<< / Tune-

Original	Replacement	Original	Replacement
Stop/ Mode	Stop / Hold		
>>/ Memory	>> / Tune+		
Quick Select 1	Red / Netflix / Search		
Quick Select 2	Green / APP / Repeat		
Quick Select 3	Yellow / YouTube / Repeat		
Quick Select 4	Blue / Prime Video / Random		
Speaker	TV/ Radio /		
Sleep	Sleep / Timer		
Dimmer	Shift + Mute / Dimmer		
Sound Mode	Audio / Lang I/II		

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	TV 1	1
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	TAPE 5	5
GAME	Game	VIDEO 4	4
CD	CD	CD-STB 3	3
MEDIA PLAYER	Media Player	HDMI-SAT 0	0
PHONO	Phono	AUX-HDD 7	7
TV AUDIO	Tv/Audio	-/-- GUIDE EPG	Guide / EPG / -/--
TUNER	Tuner	TUNER 6	6
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	PC FAV MARKER	Fav / Marker / PC
	.:I:.	LIST SMART	Smart / List
CH/PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
CH/PAGE	CH/Page-	CH PAGE –	CH- / Page-
VOLUME	Volume+	+ VOL	Vol +

Original		Replacement	
VOLUME	Volume-	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
BACK	Back	RETURN BACK	Back / Return
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	OK
►/II	Play	SLOW	Play / Slow
TUNE –	I <</ Tune-	PRESET-	I << / Preset-
►/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+
BAND	<</ Band	TUNE-	<< / Tune-
MODE	Stop/Mode	HOLD	Stop / Hold
MEMORY	>>/ Memory	TUNE+	>> / Tune+
1	Quick Select 1	NETFLIX SEARCH	Red / Netflix / Search
2	Quick Select 2	APP REPEAT	Green / APP / Repeat

Original	Replacement	Original	Replacement
3 Quick Select 3	YouTube / REPEAT A-B Yellow / YouTube / Repeat		
4 Quick Select 4	Prime Video / RANDOM Blue / Prime Video / Random		
SLEEP Sleep	TIMER / SLEEP Sleep / Timer		