Original		Replacement	
POWER	Power		Power
OPEN /CLOSE	Open / Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
STEP	Step	SHIFT + STEP - FREEZE II	Shift + Pause / Step /
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
ANGLE	Angle	ANGLE INFO	Info / Angle

Original		Replacement	
PROG	Prog	PROGRAM TV/ RADIO	TV/ Radio /
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
VIDEO	Video	LIST SMART	Smart / List
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TITLE	Title	TITLE SOUND	Sound / Title
PBC	PBC	FORMAT PICTURE	Picture / Format
GOTO	Goto	GOTO TEXT	Text / Goto
L/R	L/R	TOP MENU D.MENU	D. Menu / Top
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
^	Up	▲	Up
DISPLAY	Display	MEDIA DISPLAY	Display / Media
<	Left	◀	Left
ENTER	Enter	OK	OK
>	Right	▶	Right
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement		Original	Replacement
	Down		Down		
RETURN	Return	RETURN BACK	Back / Return		
VOL+	Vol +	VOL +	Vol +		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
<<	<<	TUNE- <<	<< / Tune-		
>>	>>	TUNE+ >>	>> / Tune+		
STOP	Stop	HOLD	Stop / Hold		
VOL-	Vol -	VOL -	Vol -		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
I<<	I <<	PRESET- I<<	I << / Preset-		
>>I	>>I	PRESET+ >>I	>>I / Preset+		
>II	Play / Pause	SLOW	Play / Slow		
>II	Play / Pause	STEP-FREEZE	Pause / Step / Freeze		