| Original | Replacement |
|---|---|
| Power | Power |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| Cancel | SHIFT + EXIT: Shift + Exit / Cancel / Clear |
| VPS/PDC | Fav / Marker / PC |
| Right VPS/PDC | Subtitle / EQ |
| AV Link | Display / Media |
| Timer Rec | Zoom / Size |
| Right Av Link | Picture / Format |
| OSD/Display | Info / Angle |
| Reset | Setup / OPT / |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |

| Original | Replacement |
|---|---|
| OK | OK |
| Play | Play / Slow |
| Stop | Stop / Hold |
| Direct Tv Rec | TV/Radio / |
| >> | >> / Tune+ |
| << | << / Tune- |
| Exit | Exit / Cancel / Clear |
| Menu | Menu / Home |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | 0 | | 0 | | |
| | -/-- | | Guide / EPG / -/-- | | |
| | AV/Input Select | | AV / Input / RDS | | |
| | Tv/Text | | Text / Goto | | |
| | Tracking/V-Lock+ | | CH+ / Page+ | | |
| | Tracking/V-Lock- | | CH- / Page- | | |
| | Pause/Slow | | Pause / Step / Freeze | | |
| | Rec | | Rec / Rec Mode | | |
| | Search | | Shift + Red / Netflix / | | |
| | I<< Index | | I<< / Preset- | | |
| | Index >>I | | >>I / Preset+ | | |
| | Vol + | | Vol + | | |
| | Vol - | | Vol - | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| | Prog/Check Up | SHIFT + ▲ | Shift + Up |
| | Prog/Check | SHIFT + ▼ | Shift + Down |
| DATE + | Date+ | SHIFT + CH PAGE + | Shift + CH+ / |
| | Date- | SHIFT + CH PAGE − | Shift + CH- / |
| ON + | On+ | TIMER SLEEP | Sleep / Timer |
| | On- | GOTO TEXT | Text / Goto |
| OFF + | Off+ | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Off- | Prime Video RANDOM | Blue / Prime Video / Random |
| PROG/CHECK | Prog/Check | -/-- GUIDE EPG | Guide / EPG / -/-- |
| CANCEL | Cancel | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |
| VPS/PDC | VPS/PDC | PC FAV MARKER | Fav / Marker / PC |
| | Right VPS/PDC | EQ SUBTITLE | Subtitle / EQ |
| TIMER REC | Timer Rec | SIZE ZOOM | Zoom / Size |
| AV LINK | AV Link | MEDIA DISPLAY | Display / Media |
| | Right Av Link | FORMAT PICTURE | Picture / Format |
| OSD/DISPLAY | OSD/Display | ANGLE INFO | Info / Angle |

| Original | | Replacement | |
|---|---|---|---|
| RESET | Reset | OPT-TOOLS SETUP | Setup / OPT / |
| DIRECT TV REC | Direct Tv Rec | PROGRAM TV/RADIO | TV/Radio / |
| | Up | ▲ | Up |
| | Down | ▼ | Down |
| | Right | ▶ | Right |
| | Left | ◀ | Left |
| OK | OK | OK | OK |
| | Play | SLOW ▶ | Play / Slow |
| | Stop | HOLD ■ | Stop / Hold |
| | >> | TUNE+ ▶▶ | >> / Tune+ |
| | << | TUNE- ◀◀ | << / Tune- |
| | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| MENU | Menu | HOME MENU | Menu / Home |
| SHOW VIEW | Show View | LANG I/II AUDIO | Audio / Lang I/II |
| | 1 | TV 1 | 1 |
| | 2 | DVD 2 | 2 |
| | 3 | CD-STB 3 | 3 |

| Original | | Replacement | |
|---|---|---|---|
| | 4 | VIDEO 4 | 4 |
| | 5 | TAPE 5 | 5 |
| | 6 | TUNER 6 | 6 |
| | 7 | AUX - HDD 7 | 7 |
| | 8 | USB 8 | 8 |
| | 9 | BLUETOOTH 9 | 9 |
| | 0 | HDMI - SAT 0 | 0 |
| | -/-- | SHIFT + GUIDE EPG | Shift + Guide / EPG / -/-- |
| TRACKING/V-LOOK | Tracking/V-Look+ | CH PAGE + | CH+ / Page+ |
| | Tracking/V-Look- | CH PAGE − | CH- / Page- |
| INPUT SELECT | AV/Input Select | RDS AV INPUT | AV / Input / RDS |
| PAUSE/SLOW | Pause/Slow | STEP - FREEZE | Pause / Step / Freeze |
| REC | Rec | REC MODE | Rec / Rec Mode |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search |
| INDEX | I<< Index | PRESET- | I<< / Preset- |
| INDEX | >>I Index | PRESET+ | >>I / Preset+ |
| | Vol + | VOL + | Vol + |

| Original | | Replacement | |
|---|---|---|---|
| | Vol - | VOL − | Vol - |