Mandis shop

42791

Original	Replacement
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Mem+	CH+ / Page+
0	0
C	Fav / Marker / PC
Mem-	CH- / Page-
Channel+	Up
People	Smart / List

Original	Replacement
Vol-	Vol-
Vol+	Vol+
→·←	Guide / EPG / -/--
Channel-	Down
Bass+	Right
Treble+	>> / Tune+
Start	Menu / Home
Bass-	Left
Treble-	<< / Tune-
End	Exit / Cancel / Clear

https://all-remote-controls.nl/en/EIS/1065938-95894-replacement-remote-control-for-EIS-42791.html