Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
USB REC	USB Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
RDS DISPLAY	>>/RDS Display	TUNE+	>> / Tune+
RDS PTY	I<<<RDS PTY	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
SOUND	Sound	TITLE SOUND	Sound / Title
CD REC SPEED	Speed/CD Rec	EQ SUBTITLE	Subtitle / EQ
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	On/Off Timer	PROGRAM TV/RADIO	TV/Radio /
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
FUNCTION	Function	HOME MENU	Menu / Home
TUNING	Up/Tuning+		Up

Original		Replacement	
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
	Enter	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TUNING	Down/Tuning-		Down
RETURN	Return	RETURN BACK	Back / Return
VOL +	Vol +	+ VOL	Vol +
DISC SKIP DVD	DVD/Disc Skip	LIST SMART	Smart / List
VOL −	Vol -	VOL −	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
DISC MENU 4	4/Disc Menu	VIDEO 4	4
TITLE MENU 5	5/Title Menu	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Replacement		Original	Replacement
SYNC 8	8/ Sync	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
DISPLAY A	Red/ Display	NETFLIX SEARCH	Red / Netflix / Search		
MO/ST TUN B	Green/ MO/ ST	APP REPEAT	Green / APP / Repeat		
C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
D	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
EQ	EQ	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ		
TIMER CLOCK	Clock/ Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer		
HOME	Home	SHIFT + HOME MENU	Shift + Menu /		
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /		