| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Zone Off | Shift + Power | CD | Shift + 3 |
| Zone On | Power | Phono | Smart / List |
| Quick Select 1 (DVD) | 1 | M.Zone Call | Display / Media |
| Quick Select 2 (SAT/CBL) | 2 | CH+ | CH+ / Page+ |
| Quick Select 3 (VCR/iPod) | 3 | Shift | Setup / OPT / |
| DVD | Shift + 2 | Vol + | Vol + |
| TV | Shift + 1 | CH- | CH- / Page- |
| iPod | Guide / EPG / -/-- | Mute | Mute / Dimmer |
| HDP | 7 | Vol - | Vol - |
| Net/USB | 8 | Menu | Menu / Home |
| SAT/CBL | 9 | Up | Up |
| VCR | 4 | Memory | Info / Angle |
| DVR | D.Menu / Top | Left | Left |
| V.AUX | Fav / Marker / PC | Enter | OK |
| Tuner | 6 | Right | Right |
| SAT TU | 0 | Search | Red / Netflix / Search |
| DTU | 5 | Down | Down |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Return | Back / Return | | |
| I<</Tuning- | I<< / Preset- | | |
| >>I/Tuning+ | >>I / Preset+ | | |
| Stop | Stop / Hold | | |
| Play | Play / Slow | | |
| Pause | Pause / Step / Freeze | | |
| Repeat | Green / APP / Repeat | | |
| Random | Blue / Prime Video / Random | | |
| USB Direct Pla | TV/Radio / | | |
| All | Audio / Lang I/II | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| ZONE OFF | Zone Off | SHIFT + | Shift + Power |
| ZONE ON | Zone On | | Power |
| (DVD) 1 | Quick Select 1 (DVD) | TV 1 | 1 |
| (SAT/CBL) 2 | Quick Select 2 (SAT/CBL) | DVD 2 | 2 |
| (VCR / iPod) 3 | Quick Select 3 (VCR/iPod) | CD - STB 3 | 3 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TV | TV | SHIFT + TV 1 | Shift + 1 |
| iPod | iPod | -/-- GUIDE EPG | Guide / EPG / -/-- |
| HDP | HDP | AUX - HDD 7 | 7 |
| NET/ USB | NET/USB | USB 8 | 8 |
| SAT/ CBL | SAT/CBL | BLUETOOTH 9 | 9 |
| VCR | VCR | VIDEO 4 | 4 |
| DVR | DVR | TOP MENU D.MENU | D. Menu / Top |
| V.AUX | V. AUX | PC FAV MARKER | Fav / Marker / PC |
| TUNER | Tuner | TUNER 6 | 6 |
| SAT TU | SAT TU | HDMI - SAT 0 | 0 |
| DTU | DTU | TAPE 5 | 5 |

| Original | | Replacement | |
|---|---|---|---|
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| PHONO | Phono | LIST SMART | Smart / List |
| M.ZONE CALL | M.Zone Call | MEDIA DISPLAY | Display / Media |
| CH + | CH+ | CH PAGE + | CH+ / Page+ |
| SHIFT | Shift | OPT-TOOLS SETUP | Setup / OPT / |
| VOL + | Vol + | VOL + | Vol + |
| CH - | CH- | CH PAGE - | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| VOL - | Vol - | VOL - | Vol - |
| MENU | Menu | HOME MENU | Menu / Home |
| Up | Up | Up | Up |
| MEMORY | Memory | ANGLE INFO | Info / Angle |
| Left | Left | Left | Left |
| ENTER | Enter | OK | OK |
| Right | Right | Right | Right |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search |
| Down | Down | Down | Down |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| RETURN | Return | RETURN BACK | Back / Return | | | | |
| TUNING▼ | I<</Tuning- | PRESET- | I<< / Preset- | | | | |
| TUNING▲ | >>I/Tuning+ | PRESET+ | >>I / Preset+ | | | | |
| | Stop | HOLD | Stop / Hold | | | | |
| | Play | SLOW | Play / Slow | | | | |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | | | | |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat | | | | |
| RANDOM | Random | Prime Video RANDOM | Blue / Prime Video / Random | | | | |
| USB | USB Direct Pla | PROGRAM TV/ RADIO | TV/Radio / | | | | |
| ALL MUSIC / FAVORITES | All | LANG I/II AUDIO | Audio / Lang I/II | | | | |

| Original | | Replacement | |
|---|---|---|---|
| ZONE OFF | Zone Off | SHIFT + | Shift + Power |
| ZONE ON | Zone On | | Power |
| (DVD) 1 | Quick Select 1 (DVD) | TV 1 | 1 |
| (SAT/CBL) 2 | Quick Select 2 (SAT/CBL) | DVD 2 | 2 |
| (VCR / iPod) 3 | Quick Select 3 (VCR/iPod) | CD - STB 3 | 3 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TV | TV | SHIFT + TV 1 | Shift + 1 |
| iPod | iPod | -/-- GUIDE EPG | Guide / EPG / -/-- |
| HDP | HDP | AUX - HDD 7 | 7 |
| NET/ USB | NET/USB | USB 8 | 8 |
| SAT/ CBL | SAT/CBL | BLUETOOTH 9 | 9 |
| VCR | VCR | VIDEO 4 | 4 |
| DVR | DVR | TOP MENU D.MENU | D. Menu / Top |
| V.AUX | V. AUX | PC FAV MARKER | Fav / Marker / PC |
| TUNER | Tuner | TUNER 6 | 6 |
| SAT TU | SAT TU | HDMI - SAT 0 | 0 |
| DTU | DTU | TAPE 5 | 5 |

| Original | | Replacement | |
|---|---|---|---|
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| PHONO | Phono | LIST SMART | Smart / List |
| M.ZONE CALL | M.Zone Call | MEDIA DISPLAY | Display / Media |
| CH + | CH+ | CH PAGE + | CH+ / Page+ |
| SHIFT | Shift | OPT-TOOLS SETUP | Setup / OPT / |
| VOL + | Vol + | VOL + | Vol + |
| CH - | CH- | CH PAGE - | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| VOL - | Vol - | VOL - | Vol - |
| MENU | Menu | HOME MENU | Menu / Home |
| Up | Up | Up | Up |
| MEMORY | Memory | ANGLE INFO | Info / Angle |
| Left | Left | Left | Left |
| ENTER | Enter | OK | OK |
| Right | Right | Right | Right |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search |
| Down | Down | Down | Down |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Return | Back / Return | | |
| I<</Tuning- | I<< / Preset- | | |
| >>I/Tuning+ | >>I / Preset+ | | |
| Stop | Stop / Hold | | |
| Play | Play / Slow | | |
| Pause | Pause / Step / Freeze | | |
| Repeat | Green / APP / Repeat | | |
| Random | Blue / Prime Video / Random | | |
| USB Direct Pla | TV/Radio / | | |
| All | Audio / Lang I/II | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Zone Off | Shift + Power | CD | Shift + 3 |
| Zone On | Power | Phono | Smart / List |
| Quick Select 1 (DVD) | 1 | M.Zone Call | Display / Media |
| Quick Select 2 (SAT/CBL) | 2 | CH+ | CH+ / Page+ |
| Quick Select 3 (VCR/iPod) | 3 | Shift | Setup / OPT / |
| DVD | Shift + 2 | Vol + | Vol + |
| TV | Shift + 1 | CH- | CH- / Page- |
| iPod | Guide / EPG / -/-- | Mute | Mute / Dimmer |
| HDP | 7 | Vol - | Vol - |
| NET/USB | 8 | Memory | Info / Angle |
| SAT/CBL | 9 | Search | Red / Netflix / Search |
| VCR | 4 | I<</Tuning- | I<< / Preset- |
| DVR | D.Menu / Top | >>I/Tuning+ | >>I / Preset+ |
| V.AUX | Fav / Marker / PC | Stop | Stop / Hold |
| Tuner | 6 | Play | Play / Slow |
| SAT TU | 0 | Pause | Pause / Step / Freeze |
| DTU | 5 | Repeat | Green / APP / Repeat |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| RANDOM | Random | Prime Video / RANDOM | Blue / Prime Video / Random | | | | |
| USB | USB Direct Pla | PROGRAM TV/ RADIO | TV/Radio / | | | | |
| ALL MUSIC / FAVORITES | All | LANG I/II AUDIO | Audio / Lang I/II | | | | |