Mandis shop

Toshiba CT-8545

Original	Replacement	Original	Replacement
Power	Power	Stop	Stop / Hold
Vol +	Vol +	123#	1
Home	Menu / Home	prime video	Blue / Prime Video / Random
P+	CH+ / Page+	Netflix	Red / Netflix / Search
Vol -	Vol -	FPay	Yellow / YouTube / Repeat
P-	CH- / Page-		
Guide	Guide / EPG / -/--		
Input	AV / Input / RDS		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Back	Back / Return		
Down	Down		
Exit	Exit / Cancel / Clear		
Smart Colors	Smart / List		
Play	Play / Slow		

https://all-remote-controls.nl/en/Toshiba/10668-9568-replacement-remote-control-for-Toshiba-CT-8545-30107761.htm