Mandis shop

RM-D420

Original		Replacement	
CONTINUE	Continue Play	LIST SMART	Smart / List
PLAY MODE SHUFFLE	Shuffle Play Mod	MEDIA DISPLAY	Display / Media
PROGRAM	Program Play	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
>10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
10	10	HDMI-SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIME	Time	TIMER SLEEP	Sleep / Timer
CHECK	Check	ANGLE INFO	Info / Angle

Original		Replacement	
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
FADER	Fader	DIMMER MUTE	Mute / Dimmer
▶	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
A ⏮	I<< AMS	PRESET- ⏮	I<< / Preset-
AMS ⏭	AMS >>I	PRESET+ ⏭	>>I / Preset+
+ LINE OUT LEVEL	Line Out Level +	+ VOL	Vol +
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
LINE OUT LEVEL −	Line Out Level	VOL −	Vol -

https://al-remotecontrols.nl/en/Sony/1678-641-replacement-remote-control-for-Sony-RM-D420-1458011.html