Original	Replacement	Original	Replacement
Standby	Power	OK	OK
Subtitle	Subtitle / EQ	Right / Vol +	Vol +
Audio	Audio / Lang I/II	Right / Vol +	Right
Mute	Mute / Dimmer	Record	Rec / Rec Mode
<<	<< / Tune-	Down / CH-	CH- / Page-
Play / Pause	Play / Slow	Down / CH-	Down
Play / Pause	Pause / Step / Freeze	Timeshift	Sleep / Timer
I <<	I << / Preset-	1	1
>>	>> / Tune+	2	2
Stop	Stop / Hold	3	3
>>I	>>I / Preset+	--	Guide / EPG / -/--
Menu	Menu / Home	4	4
Up / CH+	Up	5	5
Up / CH+	CH+ / Page+	6	6
Exit	Exit / Cancel / Clear	Recall	Back / Return
Left / Vol -	Left	7	7
Left / Vol -	Vol -	8	8

Original		Replacement		Original	Replacement
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
FAV	--	PC FAV MARKER	Fav / Marker / PC		
DEVICE	Device	LIST SMART	Smart / List		
FILE	File	MEDIA DISPLAY	Display / Media		
REPEAT	Repeat	SHIFT +	APP REPEAT Shift + Green / APP /		
TELETEXT	Teletext	GOTO TEXT	Text / Goto		
DIGEST	Mosaic	FORMAT PICTURE	Picture / Format		
TV/RADIO	TV/Radio	PROGRAM TV/ RADIO	TV/Radio /		
INFO	Info	ANGLE INFO	Info / Angle		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		