Mandis shop

REMCON2136

| Original | | Replacement | |
|---|---|---|---|
| TUNER | Tuner | TUNER 6 | 6 |
| CD | CD | CD - STB 3 | 3 |
| DOWN I<< | I<</Down | PRESET- I<< | I<< / Preset- |
| UP >>I | >>I/Up | PRESET+ >>I | >>I / Preset+ |
| ▶II | Play | SLOW ▶ | Play / Slow |
| ▶II | Pause | STEP-FREEZE II | Pause / Step / Freeze |
| M-UP REPEAT | M-Up/Repeat | APP REPEAT | Green / APP / Repeat |
| MEMORY CLOCK | Memory/Clock | TIMER SLEEP | Sleep / Timer |
| STOP | Stop | HOLD ■ | Stop / Hold |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| BAND | Band | PROGRAM TV/RADIO | TV/Radio / |
| POWER | Power | ⏻ | Power |
| – VOLUME | Volume- | VOL – | Vol- |
| VOLUME + | Volume+ | + VOL | Vol+ |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://all-remote-controls.nl/en/Roadstar/1067276-96946-replacement-remote-control-for-Roadstar-REMCON2136.html