Original	Replacement	Original	Replacement
Standby	Power	0	0
Prog	TV/Radio /	10+	Guide / EPG / -/--
Display	Display / Media	Time	Sleep / Timer
Open/Close	Eject / Surround	Setup	Setup / OPT /
N/P	Smart / List	Up	Up
1	1	Repeat	Green / APP / Repeat
2	2	Left	Left
3	3	Enter	OK
Subtitle	Subtitle / EQ	Right	Right
4	4	Vol -	Vol -
5	5	Down	Down
6	6	Vol +	Vol +
Language	Audio / Lang I/II	Return	Back / Return
7	7	Zoom	Zoom / Size
8	8	Mode	Picture / Format
9	9	Step	Shift + Pause / Step /
Angle	Info / Angle	L/R	Blue / Prime Video / Random

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
RESUME	Resume	NETFLIX SEARCH	Red / Netflix / Search
SLOW	Slow	SHIFT + SLOW	Shift + Play /
TITLE	Title	TITLE SOUND	Sound / Title
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MENU	Menu	HOME MENU	Menu / Home
PREV	I<<</Prev	PRESET-	I<< / Preset-
NEXT	>>I / Next	PRESET+	>>I / Preset+
REV	<<</Rev	TUNE-	<< / Tune-
FWD	>>/Fwd	TUNE+	>> / Tune+
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow

Original	Replacement