Original		Replacement	
	Power		Power
TV	TV	PROGRAM TV/RADIO	TV/Radio /
CAPTION	Caption	MEDIA DISPLAY	Display / Media
AV MODE	AV Mode	LIST SMART	Smart / List
RATIO	[ ]/Ratio	EQ SUBTITLE	Subtitle / EQ
INPUT	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	--/List	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0

Original		Replacement	
FLASHBK	Flahsbk	SIZE ZOOM	Zoom / Size
VOL	Vol +	+ VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
VOL	Vol -	VOL −	Vol -
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
CH PAGE	CH/Page-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PICTURE	Picture	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
SOUND	Sound	TITLE SOUND	Sound / Title
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement		Original		Replacement	
BACK	Back	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
■	Stop	HOLD ■	Stop / Hold				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
•	.	NETFLIX SEARCH	Red / Netflix / Search				
••	..	APP REPEAT	Green / APP / Repeat				
∴	.:	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
⁞⁞	::	Prime Video RANDOM	Blue / Prime Video / Random				