Mandis shop

Sony RMT-AM330U

Original		Replacement	
SCORE	Score	LIST SMART	Smart / List
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
⏻	Power	⏻	Power
PLAY MODE	Play Mode	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT/ FM MODE	Repeat/FM	APP REPEAT	Green / APP / Repeat
PARTY LIGHT	Party Light	NETFLIX SEARCH	Red / Netflix / Search
LIGHT MODE	Light Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REC TO USB	Rec To USB	REC MODE ●	Rec / Rec Mode
▲	Up	▲	Up
TUNER MENU	Tuner Menu	HOME MENU	Menu / Home
🗀–	Left/Folder-	◀	Left
✦	OK	OK	OK
🗀+	Right/Folder+	▶	Right
BACK	Back	RETURN BACK	Back / Return
▼	Down	▼	Down
OPTIONS	Options	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement	
FUNCTION	Function	TOP MENU D.MENU	D.Menu / Top
MEGA BASS	Mega Bass	TITLE SOUND	Sound / Title
SOUND FIELD	Sound Field	LANG I/II AUDIO	Audio / Lang I/II
TUNING– ◀◀	<<Tuning-	TUNE- ◀◀	<< / Tune-
▶	Play	SLOW ▶	Play / Slow
TUNING+ ▶▶	>>Tuning+	TUNE+ ▶▶	>> / Tune+
PRESET– ⏮	I<<Preset-	PRESET- ⏮	I<< / Preset-
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
PRESET+ ⏭	>>I/Preset+	PRESET+ ⏭	>>I / Preset+
VOCAL FADER	Vocal Fader	DIMMER MUTE	Mute / Dimmer
+ VOL	Vol +	+ VOL	Vol +
KEY CONTROL #	Key Control #	+ CH PAGE	CH+ / Page+
MIC ECHO	Mic Echo	PROGRAM TV/ RADIO	TV/Radio /
VOL –	Vol -	VOL –	Vol -
b	Key Control b	CH PAGE –	CH- / Page-

https://al-remotecontrols.com/Sony/1066965-replacement-remote-control-for-Sony-RMT-AM330U-1932411.htm