Mandis shop

Pioneer CU-PD046

Original		Replacement	
	Standby / On		Power
DISC 1	Disc 1	1	1
DISC 2	Disc 2	2	2
DISC 3	Disc 3	3	3
DISC 4	Disc 4	4	4
DISC 5	Disc 5	5	5
DISC 6	Disc 6	6	6
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
RANDOM	Random	Prime Video / RANDOM	Blue / Prime Video / Random
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
HI-LITE	Hi-Lite	LIST SMART	Smart / List
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio / Program

Original		Replacement	
DELETE	Delete	RETURN BACK	Back / Return
CHECK	Check	OK	OK
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear

https://all-remote-controls.nl/en/Pioneer/1067960-95901-replacement-remote-control-for-Pioneer-CU-PD104.html