Original	Replacement	Original	Replacement
Top Menu	D. Menu / Top	VCR	Shift + 4
Return	Exit / Cancel / Clear	DVD	Shift + 2
>> / >>I	>> / Tune+	Tuner / Band	Shift + 6
Display	Display / Media	Tape	Shift + 5
Play	Play / Slow	CD	Shift + 3
Stop	Stop / Hold	1	1
I << / <<	<< / Tune-	2	2
Up	Up	3	3
I << / <<	I << / Preset-	4	4
>> / >>I	>>I / Preset+	Direct Tuning / Disc	Info / Angle
Menu	Menu / Home	5	5
Left	Left	6	6
Enter	OK	≥10/-/--	>10 / -/--
Right	Right	7	7
Down	Down	8	8
Power	Power	9	9
TV	Shift + 1	0	0

Original		Replacement		Original	Replacement
EFFECT	Effect	SURROUND	Eject / Surround		
LEVEL	Level	EQ SUBTITLE	Subtitle / EQ		
–	-	CH PAGE –	CH- / Page-		
+	+	+ CH PAGE	CH+ / Page+		
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title		
SFC	SFC	LANG I/II AUDIO	Audio / Lang I/II		
TEST	Test	GOTO TEXT	Text / Goto		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
– VOLUME	Volume-	VOL –	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
DIRECT TUNING DISC	Direct Tuning	PROGRAM TV/RADIO	TV/Radio /
4	4	4	4
5	5	5	5
6	6	6	6
≧10/-/--	+10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
⏮/◀◀	⏮/<<	TUNE- ◀◀	<< / Tune-
⏮/◀◀	⏮/<<	PRESET- ⏮	⏮ / Preset-
▶▶/⏭	>>/⏭	TUNE+ ▶▶	>> / Tune+
▶▶/⏭	>>/⏭	PRESET+ ⏭	⏭ / Preset+
■	Stop	HOLD ■	Stop / Hold

Original		Replacement	
▶	Play	SLOW ▶	Play / Slow