Original		Replacement	
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Format	FORMAT PICTURE	Picture / Format
TIMER	Red / Timer	TIMER SLEEP	Sleep / Timer
CH+	Up / CH+		Up
CH-	Down / CH-		Down
TIMER	Red / Timer	NETFLIX SEARCH	Red / Netflix / Search
VOL+	Right / Vol +		Right
VOL-	Left / Vol -		Left
page	Page Up	+ CH PAGE	CH+ / Page+
VOL+	Right / Vol +	+ VOL	Vol +
VOL-	Left / Vol -	VOL −	Vol -
OK	OK	OK	OK
	Back	RETURN BACK	Back / Return
TV/R	TV/R	PROGRAM TV/RADIO	TV/Radio /
INFO	Info	ANGLE INFO	Info / Angle
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
	Fav	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
page	Page down	CH PAGE −	CH- / Page-
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
PREV	Prev	PRESET-	I<< / Preset-
NEXT	Next	PRESET+	>>I / Preset+
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
FRW	FRW	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FFW	FFW	TUNE+	>> / Tune+
7	7	AUX-HDD 7	7
	Mute	DIMMER MUTE	Mute / Dimmer
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
1	1	TV 1	1

Original		Replacement		Original	Replacement
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
Power	Power	Power	Power		
8	8	8	8		
9	9	9	9		
0	0	0	0		
List	List	SMART	Smart / List		
Lang	Lang	AUDIO	Audio / Lang I/II		
TXT	TXT	TEXT	Text / Goto		