Original		Replacement	
POWER	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CLOCK 1	1	TV 1	1
CLOCK 1	Clock	OPT-TOOLS SETUP	Setup / OPT /
TIMER 2	2	DVD 2	2
TIMER 2	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
3	3	CD-STB 3	3
TUNER MODE 4	4	VIDEO 4	4
TUNER MODE 4	Tuner Mode	ANGLE INFO	Info / Angle
REV MODE 5	5	TAPE 5	5
REV MODE 5	Rev Mode	RETURN BACK	Back / Return
RESUME 6	Resume	HOME MENU	Menu / Home
RESUME 6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
>10	+10	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
CD EDIT/CHECK 10/0	10/0	HDMI-SAT 0	0
CD EDIT/CHECK 10/0	CD Edit/Check	GOTO TEXT	Text / Goto
CLEAR	Shift Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SHUFFLE / PROGRAM	Shuffle/Program	Prime Video RANDOM	Blue / Prime Video / Random
SHUFFLE / PROGRAM	Shuffle/Program	PROGRAM TV/RADIO	TV/Radio /
PRESET	Preset Up	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET	Preset Up		Up
PRESET	Preset Down		Down
	I<<</<<	TUNE-	<< / Tune-
	I<<</<<	PRESET-	I<< / Preset-
	I<<</<<		Left
ENTER	Enter	OK	OK
	>>/>>I	TUNE+	>> / Tune+
	>>/>>I		Right
	>>/>>I	PRESET+	>>I / Preset+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original	Replacement
Preset Down	SHIFT + PRESET- (Shift + I<< / Preset-)
Play/Pause CD	STEP-FREEZE (Pause / Step / Freeze)
Play/Pause CD	SLOW (Play / Slow)
<> Tape	SHIFT + SLOW (Shift + Play /)
Stop	HOLD (Stop / Hold)
Tuner/Band	SHIFT + TUNER 6 (Shift + 6)
AUX	SHIFT + AUX-HDD 7 (Shift + 7)
Function	LIST SMART (Smart / List)
Display	MEDIA DISPLAY (Display / Media)
Dimmer	SHIFT + DIMMER MUTE (Shift + Mute / Dimmer)
Vol +	VOL + (Vol +)
Shift	TOP MENU D.MENU (D.Menu / Top)
Sleep	TIMER SLEEP (Sleep / Timer)
Vol -	VOL - (Vol -)

Original	Replacement