Mandis shop

DIGITAL-PHOTO-FRAME

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| UP | Up | | Up |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| LEFT | Left | | Left |
| ENTER | Enter | OK | OK |
| RIGHT | Right | | Right |
| FUNCTION | Function | HOME MENU | Menu / Home |
| DOWN | Down | | Down |
| OSD | OSD | MEDIA DISPLAY | Display / Media |
| I< | | PRESET- | I<< / Preset- |
| PLAY/ PAUSE | Play | SLOW | Play / Slow |
| PLAY/ PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| >I | | PRESET+ | >>I / Preset+ |
| << | | TUNE- | << / Tune- |
| STOP/ EXIT | Stop | HOLD | Stop / Hold |
| STOP/ EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| >> | | TUNE+ | >> / Tune+ |

| Original | | Replacement | |
|---|---|---|---|
| VOL+ | Vol+ | VOL | Vol+ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| VOL– | Vol- | VOL | Vol- |

https://all-remote-controls.nl/en/Aluratek/1067314-79719-replacement-remote-control-for-Aluratek-Digital-Photo-Frame.html