Mandis shop

Canon RS03

Original		Replacement	
POWER	Power		Power
AUTO SET	Auto Set	LIST SMART	Smart / List
ASPECT	Aspect	OPT-TOOLS SETUP	Setup / OPT /
INPUT	Input	RDS AV INPUT	AV / Input / RDS
AUTO PC	Auto PC	MEDIA DISPLAY	Display / Media
FOCUS	Focus	ANGLE INFO	Info / Angle
1	Up/1		Up
1	Up/1	TV 1	1
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
4	Left/4		Left
4	Left/4	VIDEO 4	4
OK	OK	OK	OK
2	Right/2		Right
2	Right/2	DVD 2	2
D.SHIFT/ KEYSTONE	Keystone/D.Shift	TOP MENU D.MENU	D.Menu / Top
3	Down/3		Down
3	Down/3	CD - STB 3	3

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
D.ZOOM	D.Zoom+	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
D.ZOOM	D.Zoom-	CH PAGE -	CH- / Page-
VOL	Vol -	VOL -	Vol -
FREEZE	Freeze	STEP - FREEZE	Pause / Step / Freeze
BLANK	Blank	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
IMAGE	Image	FORMAT PICTURE	Picture / Format
P-TIMER	P-Timer	TIMER SLEEP	Sleep / Timer
LAMP	Lamp	GOTO TEXT	Text / Goto

https://al-remotecontrols.nl/en/Canon/1697/314-replacement-remote-control-for-Canon-RS03-Y72500.htm