Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	TV Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + TAPE 5	Shift + 5
AUX2	AUX2	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PHONO	Phono	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	-/-- GUIDE EPG	Guide / EPG / -/--
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	SHIFT + BLUETOOTH 9	Shift + 9
INTERNET RADIO	Internet/Radio	PC FAV MARKER	Fav / Marker / PC
1	Favorite Station	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
FAVORITE 2	Favorite Station	SHIFT + APP REPEAT	Shift + Green / APP / Repeat

Original		Replacement	
STATION 3	Favorite Station	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
4	Favorite Station	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
CH/PAGE	CH/Page+	CH PAGE +	CH+ / Page+
InstaPrevue	InstaPrevus	LIST SMART	Smart / List
VOLUME	Vol +	VOL +	Vol +
CH/PAGE	CH/Page-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol -	VOL –	Vol -
INFO	Info	ANGLE INFO	Info / Angle
	Up		Up
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement		Original		Replacement	
TUNE –	I <</ Tune-	PRESET-	I << / Preset-	GHI 4	4	VIDEO 4	4
TUNE –	I <</ Tune-	SHIFT + TUNE-	Shift + << /	JKL 5	5	TAPE 5	5
►	Play	SLOW	Play / Slow	MNO 6	6	TUNER 6	6
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+	PQRS 7	7	AUX - HDD 7	7
TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /	TUV 8	8	USB 8	8
<<	<<	TUNE-	<< / Tune-	WXYZ 9	9	BLUETOOTH 9	9
❚❚	Pause	STEP - FREEZE	Pause / Step / Freeze	0	0	HDMI - SAT 0	0
■	Stop	HOLD	Stop / Hold				
>>	>>	TUNE+	>> / Tune+				
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat				
SOUND MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search				
MODE GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random				
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
1	1	TV 1	1				
ABC 2	2	DVD 2	2				
DEF 3	3	CD - STB 3	3				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				

https://al-remotecontrols.com/en/Denon/1507-645-replacement-remote-control-for-Denon-RC1185-001-001-001

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	TV Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + TAPE 5	Shift + 5
AUX2	AUX2	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PHONO	Phono	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	-/-- GUIDE EPG	Guide / EPG / -/--
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	SHIFT + BLUETOOTH 9	Shift + 9
INTERNET RADIO	Internet/Radio	PC FAV MARKER	Fav / Marker / PC
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search
FAVORITE 2	Favorite Station	APP REPEAT	Green / APP / Repeat

Original		Replacement	
STATION 3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random
CH/PAGE	CH/Page+	CH PAGE	CH+ / Page+
VOLUME	Vol +	VOL	Vol +
CH/PAGE	CH/Page-	CH PAGE	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol -	VOL	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<</Tune-	PRESET-	I<< / Preset-
TUNE –	I<</Tune-	SHIFT + TUNE-	Shift + <<I
	Play	SLOW	Play / Slow
TUNE +	>>I/Tune+	PRESET+	>>I / Preset+

Original	Replacement	Original	Replacement
>>I / Tune+	SHIFT + TUNE+		
<<	TUNE- << / Tune-		
Pause	STEP-FREEZE Pause / Step / Freeze		
Stop	HOLD Stop / Hold		
>>	TUNE+ >> / Tune+		
1	TV 1		
2	DVD 2		
3	CD-STB 3		
Sleep	TIMER SLEEP Sleep / Timer		
4	VIDEO 4		
5	TAPE 5		
6	TUNER 6		
7	AUX-HDD 7		
8	USB 8		
9	BLUETOOTH 9		
0	HDMI-SAT 0		

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + TAPE 5	Shift + 5
AUX2	AUX2	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PHONO	Phono	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	-/-- GUIDE EPG	Guide / EPG / -/--
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	SHIFT + BLUETOOTH 9	Shift + 9
INTERNET RADIO	Internet/Radio	PC FAV MARKER	Fav / Marker / PC
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search
FAVORIT 2	Favorite Station	APP REPEAT	Green / APP / Repeat

Original		Replacement	
STATION 3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random
CH/PAGE	CH/Page+	CH PAGE	CH+ / Page+
VOLUME	Vol +	VOL	Vol +
CH/PAGE	CH/Page-	CH PAGE	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol -	VOL	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<</Tune-	PRESET-	I<< / Preset-
TUNE –	I<</Tune-	SHIFT + TUNE-	Shift + <<I
	Play	SLOW	Play / Slow
TUNE +	>>I/Tune+	PRESET+	>>I / Preset+

Original	Replacement	Original	Replacement
>>I / Tune+	SHIFT + TUNE+		
<<	TUNE- << / Tune-		
Pause	STEP-FREEZE Pause / Step / Freeze		
Stop	HOLD Stop / Hold		
>>	TUNE+ >> / Tune+		
1	TV 1		
2	DVD 2		
3	CD-STB 3		
Sleep	TIMER SLEEP Sleep / Timer		
4	VIDEO 4		
5	TAPE 5		
6	TUNER 6		
7	AUX-HDD 7		
8	USB 8		
9	BLUETOOTH 9		
0	HDMI-SAT 0		