Original	Replacement	Original	Replacement
[ ]→	Exit / Cancel / Clear	[≡]	Text / Goto
Power	Power	Left	Left
[1|2]	Shift + Red / Netflix /	OK	OK
[↤|↦]	Shift + Green / APP /	Right	Right
[| ⏭|⏮]	Shift + Yellow / YouTube /	[⏭|⏮]	Pause / Step / Freeze
Red / Rec	Rec / Rec Mode	Down	Down
Red / Rec	Red / Netflix / Search	[...]	Subtitle / EQ
Green / <<	Green / APP / Repeat	Vol +	Vol +
Green / <<	<< / Tune-	Mute	Mute / Dimmer
Yellow / Stop	Stop / Hold	P+	CH+ / Page+
Yellow / Stop	Yellow / YouTube / Repeat	Vol -	Vol -
Blue / Play	Blue / Prime Video / Random	P-	CH- / Page-
Blue / Play	Play / Slow	1	1
White / >>	>> / Tune+	2	2
White / >>	Fav / Marker / PC	3	3
[|]	Shift + Guide / EPG / -/--	4	4
Up	Up	5	5

Original		Replacement		Original		Replacement	
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
[i+]		ANGLE INFO	Info / Angle				
0	0	HDMI - SAT 0	0				
P<P	P<P / -/--	-/-- GUIDE EPG	Guide / EPG / -/--				
[⏲]		TIMER SLEEP	Sleep / Timer				
[?]		RDS AV INPUT	AV / Input / RDS				
ZOOM	[↕] / Zoom	SIZE ZOOM	Zoom / Size				
SMART SOUND	Smart Sound	TITLE SOUND	Sound / Title				
[|<>|]		TOP MENU D.MENU	D.Menu / Top				
SMART PICTURE	Smart Picture	FORMAT PICTURE	Picture / Format				
INSTANT	Instant Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode				
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II				
DNR	DNR	RETURN BACK	Back / Return				
[▟]		OPT-TOOLS SETUP	Setup / OPT / Tools				

Original	Replacement	Original	Replacement
DVD	SHIFT + DVD 2 — Shift + 2	Vol +	VOL + — Vol +
[1| 2]	NETFLIX SEARCH — Red / Netflix / Search	Mute	DIMMER MUTE — Mute / Dimmer
[↤| →]	APP REPEAT — Green / APP / Repeat	P+	CH PAGE + — CH+ / Page+
[| ⏭ <]	YouTube REPEAT A-B — Yellow / YouTube / Repeat	Vol -	VOL − — Vol -
<<	TUNE- ◀◀ — << / Tune-	P-	CH PAGE − — CH- / Page-
Stop	HOLD ■ — Stop / Hold	1	TV 1 — 1
Play	SLOW ▶ — Play / Slow	2	DVD 2 — 2
>>	TUNE+ ▶▶ — >> / Tune+	3	CD-STB 3 — 3
[|]	SHIFT + GUIDE EPG — Shift + Guide / EPG / -/--	4	VIDEO 4 — 4
Up	▲ — Up	5	TAPE 5 — 5
[≡]	GOTO TEXT — Text / Goto	6	TUNER 6 — 6
Left	◀ — Left	7	AUX-HDD 7 — 7
OK	OK — OK	8	USB 8 — 8
Right	▶ — Right	9	BLUETOOTH 9 — 9
[⏭ <]	STEP-FREEZE ⏸ — Pause / Step / Freeze	[i +]	ANGLE INFO — Info / Angle
Down	▼ — Down	0	HDMI-SAT 0 — 0
[. . .]	EQ SUBTITLE — Subtitle / EQ	P<P / -/--	-/-- GUIDE EPG — Guide / EPG / -/--

Original	Replacement	Original	Replacement
Smart Sound	Sound / Title		
[|<>|]	D.Menu / Top		
Smart Picture	Picture / Format		
Instant Rec	Rec / Rec Mode		
[ ]	Setup / OPT /		

Original	Replacement	Original	Replacement
[ ]→	Exit / Cancel / Clear	[≡]	Text / Goto
Power	Power	Left	Left
[1|2]	Shift + Red / Netflix /	OK	OK
[↤|↦]	Shift + Green / APP /	Right	Right
[| ⏭|⏮]	Shift + Yellow / YouTube /	[⏭|⏮]	Pause / Step / Freeze
Red / Rec	Red / Netflix / Search	Down	Down
Red / Rec	Rec / Rec Mode	[...]	Subtitle / EQ
Green / <<	Green / APP / Repeat	Vol +	Vol +
Green / <<	<< / Tune-	Mute	Mute / Dimmer
Yellow / Stop	Stop / Hold	P+	CH+ / Page+
Yellow / Stop	Yellow / YouTube / Repeat	Vol -	Vol -
Blue / Play	Blue / Prime Video / Random	P-	CH- / Page-
Blue / Play	Play / Slow	1	1
White / >>	Fav / Marker / PC	2	2
White / >>	>> / Tune+	3	3
[|]	Shift + Guide / EPG / -/--	4	4
Up	Up	5	5

Original		Replacement		Original	
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
[i+]		ANGLE INFO	Info / Angle		
0	0	HDMI - SAT 0	0		
P<P	P<P / -/--	-/-- GUIDE EPG	Guide / EPG / -/--		
[⏲]		TIMER SLEEP	Sleep / Timer		
[?]		RDS AV INPUT	AV / Input / RDS		
[↕]	[↕] / Zoom	SIZE ZOOM	Zoom / Size		
Smart Sound	Smart Sound	TITLE SOUND	Sound / Title		
[|<>|]		TOP MENU D.MENU	D.Menu / Top		
Smart Picture	Smart Picture	FORMAT PICTURE	Picture / Format		
Instant Rec	Instant Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode		
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II		
DNR	DNR	RETURN BACK	Back / Return		
[▟]		OPT-TOOLS SETUP	Setup / OPT / Tools		

Original	Replacement	Original	Replacement
[ ]→	Exit / Cancel / Clear	Down	Down
Power	Power	[...]	Subtitle / EQ
[1|2]	Red / Netflix / Search	Vol +	Vol +
[↤|↦]	Green / APP / Repeat	Mute	Mute / Dimmer
[| ⏭|⏮]	Yellow / YouTube / Repeat	P+	CH+ / Page+
Rec	Rec / Rec Mode	Vol -	Vol -
<<	<< / Tune-	P-	CH- / Page-
Stop	Stop / Hold	1	1
Play	Play / Slow	2	2
>>	>> / Tune+	3	3
[|]	Shift + Guide / EPG / -/--	4	4
Up	Up	5	5
[≡]	Text / Goto	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
[⏭|⏮]	Pause / Step / Freeze	[i+]	Info / Angle

Original		Replacement		Original	Replacement
0	0	HDMI - SAT 0	0		
P<P / -/--	P<P / -/--	-/-- GUIDE EPG	Guide / EPG / -/--		
[◷]	[◷]	TIMER SLEEP	Sleep / Timer		
[?]	[?]	RDS AV INPUT	AV / Input / RDS		
[↕] / Zoom	[↕] / Zoom	SIZE ZOOM	Zoom / Size		
Smart Sound	Smart Sound	TITLE SOUND	Sound / Title		
[|<>|]	[|<>|]	TOP MENU D.MENU	D.Menu / Top		
Smart Picture	Smart Picture	FORMAT PICTURE	Picture / Format		
Instant Rec	Instant Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode		
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II		
DNR	DNR	RETURN BACK	Back / Return		
[▟]	[▟]	OPT-TOOLS SETUP	Setup / OPT /		