Original		Replacement	
PP	PP	RETURN BACK	Back / Return
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
P<P	P<P	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
--	--	-/-- GUIDE EPG	Guide / EPG / -/--
M	Menu [M]	HOME MENU	Menu / Home
i	Info [i]	ANGLE INFO	Info / Angle
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Left		Left
	Up		Up
	Right		Right
OK	OK	OK	OK
	Down		Down
V -	V -	VOL	Vol -
V +	V +	VOL	Vol +
P -	P -	CH PAGE	CH- / Page-
P +	P +	CH PAGE	CH+ / Page+
SOUND	Red / Sound	NETFLIX SEARCH	Red / Netflix / Search
SOUND	Red / Sound	TITLE SOUND	Sound / Title
PICTURE	Green / Picture	APP REPEAT	Green / APP / Repeat
PICTURE	Green / Picture	FORMAT PICTURE	Picture / Format
FEATURE	Yellow / Feature	YouTube REPEAT A-B	Yellow / YouTube / Repeat
INSTALL	Blue / Install	Prime Video RANDOM	Blue / Prime Video / Random
	Text	GOTO TEXT	Text / Goto

Original	Replacement	Original	Replacement
[≡o]	Sleep / Timer		
Hold	Stop / Hold		
[≡X]	Exit / Cancel / Clear		
Mix / PIP Swap	Smart / List		
PIP / Size	Zoom / Size		
PIP Down / [≡?]	I<< / Preset-		
PIP Up / Index	>>I / Preset+		
[TV]	TV/Radio /		
[AV]	AV / Input / RDS		