Mandis shop

Inno-Hit RC1240-2440

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
M	M	TOP MENU MENU	Menu
	--	-/-- GUIDE	Guide
	Up		Up
OK	OK	OK	Ok
	Down		Down
	Right		Right

Original		Replacement	
	Left		Left
+ P	P+	+ CH	Ch +
–	P-	CH –	Ch -
+ V	Vol+	+ VOL	Vol +
–	Vol-	VOL –	Vol -
SOUND	Red	A	Red
SOUND	Sound	SOUND DUAL	Dual
PICTURE	Green	B	Green
PICTURE	Picture	PICTURE FORMAT	Format
FEATURE	Yellow	C	Yellow
FEATURE	Feature	APP MEDIA	Media
INSTALL	Blue	D	Blue
INSTALL	Install	HOME SMART	Smart
AV	AV	TIMER AV	AV
TV	TV	SEARCH TV/R	TV/R
TXT	TXT	REPEAT TEXT	Text
	Mute	MUTE	Mute

https://all-remote-controls.nl/en/Inno-Hit/1055734-27513-replacement-remote-control-for-Inno-Hit-RC1240-2440.html