Original	Replacement	Original	Replacement
Source	AV / Input / RDS	Blue	Blue / Prime Video / Random
Power	Power	I_I	Sound / Title
Mute	Mute / Dimmer	Del	Exit / Cancel / Clear
TXT	Text / Goto	Vol +	Vol +
))[ ]	Audio / Lang I/II	Home	Menu / Home
Rec	Rec / Rec Mode	CH+	CH+ / Page+
[>]	Eject / Surround	Vol -	Vol -
Stop	Stop / Hold	Mouse	Smart / List
Play/Pause	Play / Slow	CH-	CH- / Page-
Play/Pause	Pause / Step / Freeze	Up	Up
<<	<< / Tune-	Left	Left
<<	I<< / Preset-	OK	OK
>>	>> / Tune+	Right	Right
>>	>>I / Preset+	Down	Down
Red	Red / Netflix / Search	Settings	Setup / OPT /
Green	Green / APP / Repeat	Back	Back / Return
Yellow	Yellow / YouTube / Repeat	EPG	Guide / EPG / -/--

Original		Replacement		Original	Replacement
RECALL	Recall	PC FAV MARKER	Fav / Marker / PC		
FAV	FAV	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC		
INFO	Info	ANGLE INFO	Info / Angle		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
	Subtitle	EQ SUBTITLE	Subtitle / EQ		
0	0	HDMI - SAT 0	0		
	Format	FORMAT PICTURE	Picture / Format		