Original		Replacement	
	Power		Power
OPEN/ CLOSE	Open/ Close	ZOOM	Eject
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
REPEAT	Repeat	REPEAT TEXT	Text
	I<<		I<<
	<<		<<
	>>		>>

Original		Replacement	
	>>I		>>I
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
HOME	Home	HOME SMART	Smart
MUSIC ID	Music ID	SOUND DUAL	Dual
INFO/ DISPLAY	Info/ Display	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
TITLE/ POPUP	Title/ Popup	APP MEDIA	Media
DISC MENU	Menu Disc	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
R	Red	A	Red
G	Green	B	Green

Original		Replacement	
Y	Yellow	C	Yellow
B	Blue	D	Blue
MARKER	Marker	SETTINGS OPT	Options
SEARCH	Search	SEARCH TV/R	TV/R
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
	Power Tv	SHIFT +	Shift + Power
AV/ INPUT	AV Input Tv	TIMER AV	AV
VOL+	Vol + Tv	+ VOL	Vol +
VOL-	Vol - Tv	VOL -	Vol -
PR/CH	PR/CH+ Tv	+ CH	Ch +
PR/CH	PR/CH- Tv	CH -	Ch -

Original	Replacement