Original		Replacement	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
FUNCTION	Function	HOME SMART	Smart
INPUT	Input	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
RETURN	Return	RETURN BACK	Back
EQ	EQ	APP MEDIA	Media
VSM	VSM	FAV PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
SETUP	Setup	SETTINGS OPT	Options
DISPLAY	Display	DISPLAY INFO	Info
PRESET+	Up / Preset +		Up
PRESET-	Down / Preset -		Down
TUN.-	Left / TUN-		Left
TUN.+	Right / TUN+		Right
ENTER	Enter	OK	Ok
MENU	Menu	TOP MENU MENU	Menu
TITLE	Title	SEARCH TV/R	TV/R
SCAN -	<< / Scan -		<<
SCAN +	>> / Scan +		>>
PLAY	Play	PLAY MODE	Play
SKIP -	I<< / Skip -		I<<
SKIP +	>>I / Skip +		>>I
PAUSE/STEP	Pause / Step		Pause
PROG.MEMO.	Prog. Memo	SHIFT + PROG SLEEP	Shift + Sleep

Original		Replacement	
REC	Rec	REC MODE	Rec
STOP	Stop		Stop
VOLUME +	Volume +	+ VOL	Vol +
–	Volume -	VOL –	Vol -
REPEAT	Repeat	REPEAT TEXT	Text
S-TITLE	S-Title	AD SUBT	Subt
RDS	RDS	DISC NAV LIST	List
PTY	PTY.	PICTURE FORMAT	Format
HT SPK	HT SPK	ECO 3D	3D
CLEAR	Clear	CLEAR EXIT	Exit

Original	Replacement