Original	Replacement
Mute	Mute / Dimmer
Power	Power
Timer/I□□	Sleep / Timer
[ ]/T-C	Picture / Format
Audio/Repeat	Shift + Green / APP /
Audio/Repeat	Audio / Lang I/II
[+]/Eye/SV	Display / Media
→[ ]←/Disc Menu/SP/LP	D. Menu / Top
Radio/Search/000	Shift + Red / Netflix /
Radio/Search/000	TV/Radio /
1	1
2 abc	2
3 def	3
4 ghi	4
5 jkl	5
6 mno	6
7 pqrs	7

Original	Replacement
8	8
9	9
*/EPG	Guide / EPG / -/--
0/AV	AV / Input / RDS
0/AV	0
#/PIP	Smart / List
Menu	Menu / Home
End	Exit / Cancel / Clear
Text	Text / Goto
Info	Info / Angle
P+	CH+ / Page+
Vol -	Vol -
Up	Up
Left	Left
OK	OK
Right	Right
Vol +	Vol +

Original		Replacement		Original	Replacement
	Down		Down		
	P-	CH PAGE	CH- / Page-		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		

Original	Replacement
Mute	Mute / Dimmer
Power	Power
Timer/I□□	Sleep / Timer
[ ]/T-C	Picture / Format
[+]/Eye/SV	Display / Media
-[ ]←/Disc Menu/SP/LP	D.Menu / Top
Radio/Search/000	Shift + Red / Netflix /
Radio/Search/000	TV/Radio /
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement
0/AV	AV / Input / RDS
0/AV	0
Menu	Menu / Home
End	Exit / Cancel / Clear
Text	Text / Goto
Info	Info / Angle
P+	CH+ / Page+
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
P-	CH- / Page-
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random

Original		Replacement		Original	Replacement
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		

Original	Replacement
Mute	Mute / Dimmer
Power	Power
Timer/I□□	Sleep / Timer
[ ]/T-C	Picture / Format
Audio/Repeat	Green / APP / Repeat
Audio/Repeat	Audio / Lang I/II
[+]/Eye/SV	Display / Media
→[ ]←/Disc Menu/SP/LP	D.Menu / Top
Radio/Search/000	Red / Netflix / Search
Radio/Search/000	TV/Radio /
1	1
2 abc	2
3 def	3
4 ghi	4
5 jkl	5
6 mno	6
7 pqrs	7

Original	Replacement
8 tuv	8
9 wxyz	9
0 AV	0/AV
0 AV	0/AV
MENU	Menu
END	End
INFO	Info
P+	P+
▲	Up
◀	Left
OK	OK
▶	Right
▼	Down
P-	P-
◀◀	<<
▶	Play
▶▶	>>

Original	Replacement
8	8
9	9
0/AV	0
0/AV	AV / Input / RDS
Menu	Menu / Home
End	Exit / Cancel / Clear
Info	Info / Angle
P+	CH+ / Page+
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
P-	CH- / Page-
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+

Original	Replacement
Rec	Rec / Rec Mode
Pause	Pause / Step / Freeze
Stop	Stop / Hold

Original	Replacement