Mandis shop

R- 40A01

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Source/ [≡]	AV / Input / RDS
0	0
Normal / OK/ [≡i]	OK
PR+	CH+ / Page+
Up	Up
Vol -	Vol -
Left / [≡+]	Left

Original	Replacement
Menu	Menu / Home
Right / [≡o]	Right
Vol +	Vol +
Down	Down
PR-	CH- / Page-
Sleep/ [≡♦]	Sleep / Timer
Mute	Mute / Dimmer
Recall / [≡?]	Back / Return
Red/ Skip	Red / Netflix / Search
Green/ Movie	Green / APP / Repeat
[≡x]	Exit / Cancel / Clear
Yellow/ Delete	Yellow / YouTube / Repeat
Blue/ Mode	Blue / Prime Video / Random
[≡]	Text / Goto

https://all-remote-controls.nl/en/16103-2379-replacement-remote-control-for-R-40A15-4B574A801.htm