| Original | | Replacement | |
|---|---|---|---|
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 10/0 | 10/0 | 0 | 0 |
| >10 | >10 | GUIDE | Guide |
| CLR | CLR | PRE-CH | Pre Ch |
| PLAY MODE | Play Mode | SHIFT + PLAY MODE | Shift + Play |
| GROUP/ SEARCH | Group Search | SEARCH TV/R | TV/R |
| MEMORY | Memory | REC MODE | Rec |
| ENTER | Enter | OK | Ok |
| BAND | Band | B | Green |

| Original | | Replacement | |
|---|---|---|---|
| FM MODE | FM Mode | A | Red |
| PRESET + | Tuner Preset + | ▲ | Up |
| PRESET – | Tuner Preset - | ▼ | Down |
| TUNING ▲ | Tuning Up | ▶ | Right |
| TUNING ▼ | Tuning Down | ◀ | Left |
| INPUT ▲ | Input Up | CH + | Ch + |
| INPUT ▼ | Input Down | CH – | Ch - |
| DIMMER | Dimmer | APP MEDIA | Media |
| DISPLAY | Display | DISPLAY INFO | Info |
| VOLUME ▲ | Vol + | VOL + | Vol + |
| VOLUME ▼ | Vol - | VOL – | Vol - |
| MUTING | Muting | MUTE | Mute |
| ⏸ | Pause | ⏸ | Pause |
| ▶ | Play | PLAY MODE ▶ | Play |
| ■ | Stop | ■ | Stop |
| ◀◀ | << | << | << |
| ▶▶ | >> | >> | >> |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | I << | | I << | | |
| | >>I | | >>I | | |
| RANDOM | Random | SETTINGS OPT | Options | | |
| REPEAT | Repeat | REPEAT TEXT | Text | | |
| SCROLL | Scroll | ECO 3D | 3D | | |
| PLAYLIST | Play List Up | DISC NAV LIST | List | | |
| PLAYLIST | Play List Down | PROG SLEEP | Sleep | | |
| ALBUM | Album Up | AD SUBT | Subt | | |
| ALBUM | Album Down | PICTURE FORMAT | Format | | |
| MENU | Menu | TOP MENU MENU | Menu | | |
| SELECT | Select | RETURN BACK | Back | | |
| | : Up | D | Blue | | |
| | : Down | C | Yellow | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |