Original		Replacement	
ON/STANDBY	On / Standby	Power	
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
CH +	CH +	CH +	Ch +
CH −	CH -	CH −	Ch -

Original		Replacement	
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
GUIDE/TOP MENU	Guide / Top Menu	E-MANUAL D.MENU	D. Menu
GUIDE/TOP MENU	Guide / Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
GUIDE/TOP MENU	Guide / Top Menu	-/-- GUIDE	Guide
PREV CH/MENU	Prev CH / Menu	TOP MENU MENU	Menu
PREV CH/MENU	Prev CH / Menu	FAV PRE-CH	Pre Ch
▲	Up	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Category	◀	Left
ENTER	Enter	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category	▶	Right
▼	Down	▼	Down
SETUP	Setup	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
RETURN	Return	RETURN BACK	Back
⏮	I<<	⏮	I<<
⏭	>>I	⏭	>>I

Original		Replacement	
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause / Play Reverse		Pause
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Search	A	Red
MOVIE/TV SEARCH	Movie/TV / Search	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Replacement	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
D.TUN +10 DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
D.TUN +10 DIMMER	D.Tun Tuner	APP MEDIA	Media
CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original		Replacement		
ON/STANDBY	On/Standby	Power		
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1	
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2	
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3	
GAME	Input Game	SHIFT + 4	Shift + 4	
AUX	Input AUX	SHIFT + 5	Shift + 5	
TUNER	Input Tuner	SHIFT + 6	Shift + 6	
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7	
PORT	Input Port	SHIFT + 8	Shift + 8	
TONE	Tone	SHIFT + OK	Shift + Ok	
+	Tone +	SHIFT + ▲	Shift + Up	
−	Tone -	SHIFT + ▼	Shift + Down	
TUN MODE	Tun Mode	HOME SMART	Smart	
MUTING	Muting	MUTE	Mute	
VOL +	Vol +	VOL +	Vol +	
VOL −	Vol -	VOL −	Vol -	
ON/STANDBY	On/Standby	SHIFT + Power	Shift + Power	

Original		Replacement		
DISPLAY	Display BD/DVD	DISPLAY INFO	Info	
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	SHIFT + TOP MENU MENU	Shift + Menu	
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	E-MANUAL D.MENU	D. Menu	
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	GUIDE	Guide	
PREV CH/MENU	Prev CH / Menu BD/DVD	TOP MENU MENU	Menu	
PREV CH/MENU	Prev CH / Menu BD/DVD	FAV PRE-CH	Pre Ch	
	Up BD/DVD	▲	Up	
PLAYLIST /CATEGORY	Left / Playlist/Categor	◀	Left	
ENTER	Enter BD/DVD	OK	Ok	
PLAYLIST /CATEGORY	Right / Playlist/Categor	▶	Right	
	Down BD/DVD	▼	Down	
SETUP	Setup BD/DVD	SETTINGS OPT	Options	
AUDIO	Audio BD/DVD	SOUND DUAL	Dual	
RETURN	Return BD/DVD	RETURN BACK	Back	
	I<< BD/DVD	I<<	I<<	
	>>I BD/DVD	>>I	>>I	
	<< BD/DVD	<<	<<	

Original		Replacement	
	Play BD/DVD	PLAY MODE	Play
	>> BD/DVD		>>
	Pause BD/DVD		Pause
	Stop BD/DVD		Stop
MOVIE/TV SEARCH	Movie/TV / Searc BD/DVD	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc BD/DVD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat BD/DVD	B	Green
MUSIC REPEAT	Music / Repeat BD/DVD	REPEAT TEXT	Text
GAME RANDOM	Game / Random BD/DVD	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	SHIFT + PLAY MODE	Shift + Play
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6

Original		Replacement	
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
0	0 BD/DVD	0	0
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
CLR SLEEP	CLR / Sleep	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep	PROG SLEEP	Sleep

Original		Replacement	
ON/STANDBY	On / Standby		Power
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input Aux	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
ON/STANDBY	On / Standby	SHIFT +	Shift + Power

Original		Replacement	
DISPLAY	Display TV/CD	DISPLAY INFO	Info
DISC + ALBUM	Disc + / Album + TV/CD	CH +	Ch +
DISC − ALBUM	Disc - / Album - TV/CD	CH −	Ch -
	Up TV/CD	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Category	◀	Left
ENTER	Enter TV/CD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category	▶	Right
	Down TV/CD	▼	Down
SETUP	Setup TV/CD	SETTINGS OPT	Options
AUDIO	Audio TV/CD	SOUND DUAL	Dual
RETURN	Return TV/CD	RETURN BACK	Back
I<<	I<< TV/CD	I<<	I<<
>>I	>>I TV/CD	>>I	>>I
<<	<< TV/CD	<<	<<
>>	>> TV/CD	>>	>>
►	Play TV/CD	PLAY MODE ▶	Play
❚❚	Pause TV/CD	❚❚	Pause

Original		Replacement	
STOP	Stop TV/CD	STOP	Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green
MUSIC REPEAT	Music / Repeat TV/CD	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode TV/CD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode TV/CD	SHIFT + PLAY MODE	Shift + Play
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9

Original		Replacement	
0	0 TV/CD	0	0
+10 D.TUN DIMMER	+10 / Dimmer	-/-- GUIDE	Guide
CLR SLEEP	CLR / Sleep TV/C	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep TV/C	PROG SLEEP	Sleep

Original		Replacement		Original		Replacement	
ON/STANDBY	On / Standby		Power	DISPLAY	Display Port	DISPLAY INFO	Info
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1	CH +	CH + Port	CH +	Ch +
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2	CH -	CH - Port	CH -	Ch -
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3		Up Port		Up
GAME	Input Game	SHIFT + 4	Shift + 4	PLAYLIST /CATEGORY	Left / Playlist/Categor		Left
AUX	Input AUX	SHIFT + 5	Shift + 5	ENTER	Enter Port	OK	Ok
TUNER	Input Tuner	SHIFT + 6	Shift + 6	PLAYLIST /CATEGORY	Right / Playlist/Categor		Right
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7		Down Port		Down
PORT	Input Port	SHIFT + 8	Shift + 8	SETUP	Setup Port	SETTINGS OPT	Options
TONE	Tone	SHIFT + OK	Shift + Ok	RETURN	Return Port	RETURN BACK	Back
+	Tone +	SHIFT +	Shift + Up		I<< Port		I<<
-	Tone -	SHIFT +	Shift + Down		>>I Port		>>I
TUN MODE	Tun Mode	HOME SMART	Smart		<< Port		<<
MUTING	Muting	MUTE	Mute		Play Port	PLAY MODE	Play
VOL	Vol +	VOL	Vol +		>> Port		>>
VOL	Vol -	VOL	Vol -		Pause / Play Reverse Port		Pause
ON/STANDBY	On / Standby Por	SHIFT +	Shift + Power		Stop Port		Stop

Original		Replacement		Original		Replacement	
MOVIE/TV SEARCH	Movie/TV / Search Port	A	Red	+10 / D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
MOVIE/TV SEARCH	Movie/TV / Search Port	SEARCH TV/R	TV/R	CLR SLEEP	CLR / Sleep Port	CLEAR EXIT	Exit
MUSIC REPEAT	Music / Repeat	B	Green	CLR SLEEP	CLR / Sleep Port	PROG SLEEP	Sleep
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text				
GAME RANDOM	Game / Random	C	Yellow				
STEREO PLAY MODE	Stereo / Play Mode Port	D	Blue				
STEREO PLAY MODE	Stereo / Play Mode Port	SHIFT + PLAY MODE	Shift + Play				
1	1 Port	1	1				
2	2 Port	2	2				
3	3 Port	3	3				
4	4 Port	4	4				
5	5 Port	5	5				
6	6 Port	6	6				
7	7 Port	7	7				
8	8 Port	8	8				
9	9 Port	9	9				
0	0 Port	0	0				