Mandis shop

Onkyo RC-223S

Original	Replacement	Original	Replacement
Power	Power	▶▶ Deck A	Up
Sleep	Sleep / Timer	◀◀ Deck B	Shift + Down
Tape 2	2	▶▶ Deck B	Shift + Up
Tape 1	1	❚❚ CD	Pause / Step / Freeze
Tape 1	5	▶ CD	Play / Slow
Tuner	6	Tuner Preset	CH- / Page-
CD	3	Tuner Preset Up	CH+ / Page+
Phono	4	Disc CD	Display / Media
◀ Deck A	Left	■ CD	Stop / Hold
▶ Deck A	Right	Tuner CLASS	Smart / List
◀ Deck B	Shift + Left	Volume Up	Vol +
▶ Deck B	Shift + Right	❚◀◀ CD	I << / Preset-
●/❚❚ Deck A	Info / Angle	▶▶❚ CD	>>I / Preset+
■ Deck A	OK	Audio Mute	Mute / Dimmer
●/❚❚ Deck B	Shift + Info / Angle	Volume Down	Vol -
■ Deck B	Shift + OK		
◀◀ Deck A	Down		

https://all-remote-controls.nl/en/Onkyo/16010-250-replacement-remote-control-for-Onkyo-RC-223S.htm