Mandis shop

Onkyo RC-764M Receiver - VCR/DVR - CBL/SAT - Game - Aux - Tuner

Original	Replacement	Original	Replacement
On / Standby	Power	Guide / Top Menu	Guide
Display	Info	Prev CH / Menu	Menu
Input BD/DVD	Shift + 1	Prev CH / Menu	Pre Ch
Input VCR/DVR	Shift + 2	Up	Up
Input CBL/SAT	Shift + 3	Left / Playlist/Category	Left
Input Game	Shift + 4	Enter	Ok
Input AUX	Shift + 5	Right / Playlist/Category	Right
Input Tuner	Shift + 6	Down	Down
Input TV/CD	Shift + 7	Setup	Options
Input Port	Shift + 8	Audio	Dual
Muting	Mute	Return	Back
CH +	Ch +	I <<	I <<
CH -	Ch -	>>I	>>I
Vol +	Vol +	<<	<<
Vol -	Vol -	Play	Play
Guide / Top Menu	D. Menu	>>	>>
Guide / Top Menu	Shift + Menu	Pause / Play Reverse	Pause

Original		Replacement	
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Searc	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
11 0	0	0	0
--/--- 10 +10 D.TUN DIMMER	+10 / Dimmer	SHIFT + -/-- GUIDE	Shift + Guide
--/--- 10 +10 D.TUN DIMMER	D.Tun Tuner	APP MEDIA	Media
12 CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
12 CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original		Replacement	
ON/STANDBY	On/Standby		Power
BD/DVD	Input BD/DVD	SHIFT +	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT +	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT +	Shift + 3
GAME	Input Game	SHIFT +	Shift + 4
AUX	Input AUX	SHIFT +	Shift + 5
TUNER	Input Tuner	SHIFT +	Shift + 6
TV/CD	Input TV/CD	SHIFT +	Shift + 7
PORT	Input Port	SHIFT +	Shift + 8
MUTING	Muting	MUTE	Mute
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
ON/STANDBY	On/Standby	SHIFT +	Shift + Power
DISPLAY	Display BD/DVD	DISPLAY INFO	Info
GUIDE/TOP MENU SP LAYOUT	Guide / Top Menu BD/DVD	SHIFT + TOP MENU MENU	Shift + Menu
GUIDE/TOP MENU SP LAYOUT	Guide / Top Menu BD/DVD	E-MANUAL D.MENU	D. Menu
GUIDE/TOP MENU SP LAYOUT	Guide / Top Menu BD/DVD	-/-- GUIDE	Guide

Original		Replacement	
PREV CH/MENU VIDEO	Prev CH / Menu BD/DVD	TOP MENU MENU	Menu
PREV CH/MENU VIDEO	Prev CH / Menu BD/DVD	FAV PRE-CH	Pre Ch
	Up BD/DVD		Up
PLAYLIST /CATEGORY	Left / Playlist/Categor		Left
ENTER	Enter BD/DVD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Categor		Right
	Down BD/DVD		Down
SETUP	Setup BD/DVD	SETTINGS OPT	Options
AUDIO	Audio BD/DVD	SOUND DUAL	Dual
RETURN	Return BD/DVD	RETURN BACK	Back
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	Play BD/DVD	PLAY MODE	Play
	>> BD/DVD		>>
	Pause BD/DVD		Pause
	Stop BD/DVD		Stop

Original		Replacement	
MOVIE/TV SEARCH	Movie/TV / Searc BD/DVD	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc BD/DVD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat BD/DVD	B	Green
MUSIC REPEAT	Music / Repeat BD/DVD	REPEAT TEXT	Text
GAME RANDOM	Game / Random BD/DVD	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	SHIFT + PLAY MODE ▶	Shift + Play
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
0	0 BD/DVD	0	0

Original		Replacement	
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
CLR SLEEP	CLR / Sleep	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep	PROG SLEEP	Sleep

Original		Replacement	
ON/STANDBY	On / Standby		Power
BD/DVD	Input BD/DVD	SHIFT +	1
VCR/DVR	Input VCR/DVR	SHIFT +	2
CBL/SAT	Input CBL/SAT	SHIFT +	3
GAME	Input Game	SHIFT +	4
AUX	Input Aux	SHIFT +	5
TUNER	Input Tuner	SHIFT +	6
TV/CD	Input TV/CD	SHIFT +	7
PORT	Input Port	SHIFT +	8
MUTING	Muting	MUTE	Mute
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
ON/STANDBY	On / Standby	SHIFT +	Power
DISPLAY	Display TV/CD	DISPLAY INFO	Info
CH DISC	Disc + / Album + TV/CD	CH +	Ch +
ALBUM	Disc - / Album - TV/CD	CH -	Ch -
	Up TV/CD		Up

Original		Replacement	
PLAYLIST /CATEGORY	Left / Playlist/Category		Left
ENTER	Enter TV/CD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category		Right
	Down TV/CD		Down
SETUP	Setup TV/CD	SETTINGS OPT	Options
AUDIO	Audio TV/CD	SOUND DUAL	Dual
RETURN	Return TV/CD	RETURN BACK	Back
	I<< TV/CD		I<<
	>>I TV/CD		>>I
	<< TV/CD		<<
	>> TV/CD		>>
	Play TV/CD	PLAY MODE	Play
	Pause TV/CD		Pause
	Stop TV/CD		Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green

Original		Replacement		Original	Replacement
MUSIC REPEAT	Music / Repeat TV/CD	REPEAT TEXT	Text		
GAME RANDOM	Game / Random	C	Yellow		
STEREO PLAY MODE	Stereo / Play Mode TV/CD	D	Blue		
STEREO PLAY MODE	Stereo / Play Mode TV/CD	SHIFT + PLAY MODE	Shift + Play		
1	1 TV/CD	1	1		
2	2 TV/CD	2	2		
3	3 TV/CD	3	3		
4	4 TV/CD	4	4		
5	5 TV/CD	5	5		
6	6 TV/CD	6	6		
7	7 TV/CD	7	7		
8	8 TV/CD	8	8		
9	9 TV/CD	9	9		
11 0	0 TV/CD	0	0		
--/--- 10 +10 D.TUN DIMMER	+10 / Dimmer	-/-- GUIDE	Guide		
12 CLR SLEEP	CLR / Sleep TV/C	CLEAR EXIT	Exit		
12 CLR SLEEP	CLR / Sleep TV/C	PROG SLEEP	Sleep		

Original	Replacement	Original	Replacement
On / Standby	Power	Left / Playlist/Category	Left
Input BD/DVD	Shift + 1	Enter Port	Ok
Input VCR/DVR	Shift + 2	Right / Playlist/Category	Right
Input CBL/SAT	Shift + 3	Down Port	Down
Input Game	Shift + 4	Setup Port	Options
Input AUX	Shift + 5	Return Port	Back
Input Tuner	Shift + 6	I << Port	I <<
Input TV/CD	Shift + 7	>>I Port	>>I
Input Port	Shift + 8	<< Port	<<
Muting	Mute	Play Port	Play
Vol +	Vol +	>> Port	>>
Vol -	Vol -	Pause / Play Reverse Port	Pause
On / Standby Por	Shift + Power	Stop Port	Stop
Display Port	Info	Movie/TV / Searc Port	Red
CH + Port	Ch +	Movie/TV / Searc Port	TV/R
CH - Port	Ch -	Music / Repeat	Green
Up Port	Up	Music / Repeat	Text

Port

Original	Replacement	Original	Replacement
GAME RANDOM Game / Random	C Yellow		
STEREO PLAY MODE Stereo / Play Mode Port	D Blue		
STEREO PLAY MODE Stereo / Play Mode Port	SHIFT + PLAY MODE ▶ Shift + Play		
1 1 Port	1 1		
2 2 Port	2 2		
3 3 Port	3 3		
4 4 Port	4 4		
5 5 Port	5 5		
6 6 Port	6 6		
7 7 Port	7 7		
8 8 Port	8 8		
9 9 Port	9 9		
0 11 0 Port	0 0		
--/--- 10 +10 D.TUN DIMMER +10 / Dimmer	-/-- GUIDE Guide		
12 CLR SLEEP CLR / Sleep Port	CLEAR EXIT Exit		
12 CLR SLEEP CLR / Sleep Port	PROG SLEEP Sleep		