Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last View		Pre Ch
	Radio/Tv		TV/R
	Internet		Smart
	Netflix		Media
	Rec		Rec
	Prog/Check		Sleep

Original		Replacement	
	Play		Play
	>>		>>
	<<		<<
	Pause		Pause
	>>I		>>I
	I <<		I <<
	Stop		Stop
	Exit		Exit
	i/Status		Info
	Return		Back
	Guide		Guide
	Function Menu		Menu
	Video Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
OK	OK	OK	Ok
OPTION	Option	SETTINGS OPT	Options
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
AUDIO	Audio	SOUND DUAL	Dual
DRIVE SELECT	Drive Select	DISC NAV LIST	List
TEXT	Text	REPEAT TEXT	Text
STTL	STTL	AD SUBT	Subt
+60s	+60s	ECO 3D	3D
-10s	-10s	PICTURE FORMAT	Format
PAGE CH	Page/ CH+	+ CH	Ch +
CH	Page/ CH-	CH −	Ch -
+ VOL	Tv Vol +	+ VOL	Vol +
VOL −	Tv Vol -	VOL −	Vol -
INPUT AV	AV Input Tv	TIMER AV	AV

Original		Replacement	
CH	CH+ Tv	SHIFT + + CH	Shift + Ch +
CH	CH- Tv	SHIFT + CH −	Shift + Ch -
	Power Tv	SHIFT +	Shift + Power