Original	Replacement	Original	Replacement
Power	Power	0	0
Sleep	Sleep	≧10	Guide
Clock/Timer	Shift + AV	Del	Back
Play/Rec	Eject	CD Play/Pause	Play
Program	Shift + Sleep	CD Play/Pause	Up
Play Mode	Shift + Play	Tuner/Band	TV/R
Repeat	Text	Tuner/Band	Left
Music Port	Media	Stop / Clear	Exit
1	1	Stop / Clear	Stop
2	2	Stop / Clear	Ok
3	3	USB Play/Pause	Pause
4	4	Tape Play	Rec
5	5	USB Play/Pause	Right
6	6	Tape Play	Down
7	7	Vol -	Vol -
8	8	Vol +	Vol +
9	9	← Album	Ch -

Original		Replacement		Original	Replacement
BUM	Album →	+ CH	Ch +		
V/REW	I << / V / REW	I<<	I <<		
V/REW	I << / V / REW	<<	<<		
Λ/FF	>>I / Λ / FF	>>I	>>I		
Λ/FF	>>I / Λ / FF	>>	>>		
ENTER	Enter	HOME SMART	Smart		
SURROUND	Surround	SHIFT + SOUND DUAL	Shift + Dual		
PRESET EQ	Preset EQ	SETTINGS OPT	Options		
BASS/ TREBLE	Bass/Treble	SOUND DUAL	Dual		
DISPLAY	Display	DISPLAY INFO	Info		
DIMMER	Dimmer	ECO 3D	3D		
AUTO OFF	Auto Off	TIMER AV	AV		
MUTING	Muting	MUTE	Mute		