Original		Replacement	
	Power		Power
TV/TEXT	Tv/Text	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT SELECT AV	AV/Input Selec	TIMER AV	AV
-/--	-/--	-/-- GUIDE	Guide
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH	Ch +
TRACKING/V-LOCK −	Tracking/V-Lock-	CH −	Ch -
VOLUME +	Vol +	+ VOL	Vol +

Original		Replacement	
	Vol -	VOL −	Vol -
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
SHOW VIEW	Show View	HOME SMART	Smart
OSD/DISPLAY	OSD/Display	DISPLAY INFO	Info
REPLAY	Replay	FAV PRE-CH	Pre Ch
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
INDEX	I<< Index	I<<	I<<
INDEX >>I	Index >>I	>>I	>>I
REC	Rec	REC MODE	Rec
II/I▶	Pause/Step	II	Pause
MENU	Menu	TOP MENU MENU	Menu
OK	OK	OK	Ok
▷	Play/Up	PLAY MODE ▶	Play
□	Stop/Down	■	Stop
▶▶	>>/Right	>>	>>
◀◀	<<Left	<<	<<
SP/LP	SP/LP	PICTURE FORMAT	Format

Original	Replacement	Original	Replacement
TIMER REC Timer Rec	ECO 3D 3D	EXIT Exit	CLEAR EXIT Exit
PROG/CHECK Prog/Check	PROG SLEEP Sleep		
RESET Reset	RETURN BACK Back		
AUDIO Audio	SOUND DUAL Dual		
VPS/PDC VPS/PDC	AD SUBT Subt		
AV LINK AV Link	APP MEDIA Media		
TV ASPECT TV Aspect	ZOOM Eject		
Still Album	DISC NAV LIST List		
Up	Up		
Down	Down		
DATE+ Date+	Right		
DATE- Date-	Left		
ON+ On+	A Red		
ON- On-	B Green		
OFF+ Off+	C Yellow		
OFF- Off-	D Blue		
CANCEL Cancel	E-MANUAL D.MENU D. Menu		

Original		Replacement	
	Power		Power
TV/TEXT	TV/Text	REPEAT TEXT	Text
TRACKING/V-LOCK	CH+	+ CH	Ch +
	CH-	CH −	Ch -
VOLUME +	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide

Original		Replacement	
INPUT SELECT AV	AV Input Selec	TIMER AV	AV
	Red	A	Red
+ DATE	Green	B	Green
+ ON	Yellow	C	Yellow
+ OFF	Blue	D	Blue