Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
[<>]	Picture / Format
>I <	D. Menu / Top
[1I 2]	Setup / OPT /
[≡]	Text / Goto
Source	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i +]	Info / Angle
Left	Left
OK	OK

Original	Replacement
Right	Right
Down	Down
Vol +	Vol +
[-O-] / Active Control	Smart / List
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Guide	Guide / EPG / -/--

Original	Replacement
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK
Right AMP	Shift + Right
Down AMP	Shift + Down

Original	Replacement
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0
P<P AMP	Shift + Fav / Marker / PC

Original	Replacement	Original	Replacement
Power	Power	P-	CH- / Page-
Guide	Guide / EPG / -/--	1	1
Source	AV / Input / RDS	2	2
>I<	D. Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
[i+]	Info / Angle	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	0	0
[≡]	Text / Goto	P<P	Fav / Marker / PC
Menu	Menu / Home	<<	<< / Tune-
Vol +	Vol +	Stop	Stop / Hold
Mute	Mute / Dimmer	Play	Play / Slow
P+	CH+ / Page+	>>	>> / Tune+
Vol -	Vol -	[<>]	Picture / Format

Original	Replacement	Original	Replacement
[-O-]/Active Control	Smart / List		

Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
[<>]	Picture / Format
>I <	D. Menu / Top
[1I 2]	Setup / OPT /
Source	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i +]	Info / Angle
Left	Left
OK	OK
Right	Right

Original	Replacement
Down	Down
Vol +	Vol +
[-O-] / Active Control	Smart / List
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
P<P	Fav / Marker / PC

Original	Replacement
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Power VCR	Shift + Power
Play VCR	Shift + Play /
Stop VCR	Shift + Stop /
Rec VCR	Shift + Rec / Rec Mode
<< VCR	Shift + << /
>> VCR	Shift + >> /
>I < VCR	Shift + D.Menu / Top Menu
Source VCR	Shift + AV / Input / RDS
Menu VCR	Shift + Menu /
Up VCR	Shift + Up
[i +] VCR	Shift + Info / Angle
Left VCR	Shift + Left
OK VCR	Shift + OK

Original	Replacement
Right VCR	Shift + Right
Down VCR	Shift + Down
P+ VCR	Shift + CH+ /
P- VCR	Shift + CH- /
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
P<P VCR	Shift + Fav / Marker / PC

Original	Replacement
Power	Power
Guide	Guide / EPG / -/--
>I <	D. Menu / Top
[i +]	Info / Angle
Up	Up
Left	Left
Right	Right
Down	Down
Vol +	Vol +
Mute	Mute / Dimmer
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4

Original	Replacement
5	5
6	6
7	7
8	8
9	9
0	0
P<P	Fav / Marker / PC
<<	<< / Tune-
Stop	Stop / Hold
Play	Play / Slow
>>	>> / Tune+