Original	Replacement	Original	Replacement
Power	Power	Left	Left
Mute	Mute / Dimmer	OK	OK
Play	Play / Slow	Right	Right
Stop	Stop / Hold	Down	Down
Rec	Rec / Rec Mode	Vol +	Vol +
<<	<< / Tune-	[-O-] / Active Control	Smart / List
>>	>> / Tune+	P+	CH+ / Page+
(O	Audio / Lang I/II	Vol -	Vol -
[<>]	Picture / Format	P-	CH- / Page-
Green/Timer	Sleep / Timer	1	1
>I<	D.Menu / Top	2	2
[1I2]	Setup / OPT /	3	3
[≡]	Text / Goto	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8

Original	Replacement
9	9
Guide	Guide / EPG / -/--
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK

Original	Replacement
Right AMP	Shift + Right
Down AMP	Shift + Down
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0

Original	Replacement	Original	Replacement
P<P AMP	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		

Original		Replacement	
	Power		Power
	Source		AV / Input / RDS
	>>		>> / Tune+
	<<		<< / Tune-
	Stop		Stop / Hold
	Play		Play / Slow
	Guide		Guide / EPG / -/--
	[≡]		Text / Goto
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	>I<		D. Menu / Top
	Menu		Menu / Home
	Vol +		Vol +
	Mute		Mute / Dimmer

Original		Replacement	
	P+		CH+ / Page+
	Vol -		Vol -
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	[i+]		Info / Angle
	0		0
	P<P		Fav / Marker / PC
	[1|2]		Setup / OPT /
	[-O-]/Active Control		Smart / List

Original	Replacement	Original	Replacement
[<>]	FORMAT PICTURE Picture / Format		

Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
(O	Audio / Lang I/II
[<>]	Picture / Format
Green/Timer	Sleep / Timer
>I<	D.Menu / Top
[1I2]	Setup / OPT /
Source	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i+]	Info / Angle
Left	Left

Original	Replacement
OK	OK
Right	Right
Down	Down
Vol +	Vol +
[-O-]/Active Control	Smart / List
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement
0	HDMI - SAT 0
P<P	PC FAV MARKER
Red	NETFLIX SEARCH
Green/Timer	APP REPEAT
Yellow/[ ]	YouTube REPEAT A-B
Blue/[...]	Prime Video RANDOM
Power VCR	SHIFT +
Play VCR	SHIFT + SLOW
Stop VCR	SHIFT + HOLD
Rec VCR	SHIFT + REC MODE
<< VCR	SHIFT + TUNE-
>> VCR	SHIFT + TUNE+
>I < VCR	SHIFT + TOP MENU D.MENU
Source VCR	SHIFT + RDS AV INPUT
Menu VCR	SHIFT + HOME MENU
Up VCR	SHIFT +
[i+] VCR	SHIFT + ANGLE INFO

Original	Replacement
Left VCR	SHIFT +
OK VCR	SHIFT + OK
Right VCR	SHIFT +
Down VCR	SHIFT +
P+ VCR	SHIFT + CH PAGE
P- VCR	SHIFT + CH PAGE
1 VCR	SHIFT + TV 1
2 VCR	SHIFT + DVD 2
3 VCR	SHIFT + CD - STB 3
4 VCR	SHIFT + VIDEO 4
5 VCR	SHIFT + TAPE 5
6 VCR	SHIFT + TUNER 6
7 VCR	SHIFT + AUX - HDD 7
8 VCR	SHIFT + USB 8
9 VCR	SHIFT + BLUETOOTH 9
0 VCR	SHIFT + HDMI - SAT 0
P<P VCR	SHIFT + PC FAV MARKER

Shift + Left
Shift + OK
Shift + Right
Shift + Down
Shift + CH+ /
Shift + CH- /
Shift + 1
Shift + 2
Shift + 3
Shift + 4
Shift + 5
Shift + 6
Shift + 7
Shift + 8
Shift + 9
Shift + 0
Shift + Fav / Marker / PC

Original		Replacement	
	Power		Power
	>>	TUNE+	>> / Tune+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	>I <	TOP MENU D.MENU	D. Menu / Top
	Vol +	VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
	P+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	P-	CH PAGE	CH- / Page-
	1	TV 1	1

Original		Replacement	
	2	DVD 2	2
	3	CD - STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	[i +]	ANGLE INFO	Info / Angle
	0	HDMI - SAT 0	0
	P<P	PC FAV MARKER	Fav / Marker / PC