Original		Replacement	
STANDBY /ON	Standbt / On		Power
TV /AUX	TV/ AUX	A	Red
TUNER /BAND	Tuner / Band	B	Green
DVD /CD	DVD/ CD	C	Yellow
TEST TONE CH LEVEL	CH Level	TIMER AV	AV
TEST TONE CH LEVEL	Test Tone	HOME SMART	Smart
SURROUND MODE	Surround Mode	PICTURE FORMAT	Format
DSP	DSP	ECO 3D	3D
VOLUME +	Vol +	+ VOL	Vol +
VOLUME −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
DVD SETUP	DVD Setup	E-MANUAL D.MENU	D. Menu
SYSTEM SETUP	System Setup	SETTINGS OPT	Options
TOP MENU MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
TOP MENU MENU	Menu	TOP MENU MENU	Menu
SOUND	Sound	SOUND DUAL	Dual
▲	Up	▲	Up

Original		Replacement	
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok
■	Stop	■	Stop
►/II	Play	PLAY MODE ▶	Play
►/II	Pause	II	Pause
− PREV ⏮	I <<</ Prev-	⏮	I <<
STEP ◀II	◁ Step/ Slow	CH −	Ch -
STEP ◀II	<<	<<	<<
SLOW II▶	Step/ Slow I >	+ CH	Ch +
SLOW II▶	>>	>>	>>
NEXT + ⏭	>>I / Next +	>>I	>>I
RETURN	Return	RETURN BACK	Back
CONDITION 1	1	1	1
LAST MEMO 2	2	2	2
SEARCH 3	3	3	3

Original		Replacement	
ANGLE 4	4	4	4
MONO 5	5	5	5
SLEEP 6	6	6	6
PROGRAM 7	7	7	7
RANDOM 8	8	8	8
REPEAT 9	9	9	9
REP A-B 10/0	10/0	0	0
FL DIMMER >10	>10	-/-- GUIDE	Guide
CONDITION 1	Condition	SHIFT + SETTINGS OPT	Shift + Options
ANGLE 4	Angle	SHIFT + AD SUBT	Shift + Subt
MONO 5	Mono	SHIFT + ECO 3D	Shift + 3D
LAST MEMO 2	Last Memo	FAV PRE-CH	Pre Ch
SEARCH 3	Search	SEARCH TV/R	TV/R
SLEEP 6	Sleep	PROG SLEEP	Sleep
PROGRAM 7	Program	SHIFT + PROG SLEEP	Shift + Sleep
RANDOM 8	Random	SHIFT + APP MEDIA	Shift + Media
REPEAT 9	Repeat	REPEAT TEXT	Text

Original		Replacement	
REP A-B 10/0	Repeat A-B	SHIFT + REPEAT TEXT	Shift + Text
FL DIMMER >10	FL Dimmer	SHIFT + DISPLAY INFO	Shift + Info
DVD DISP CLEAR	Clear	CLEAR EXIT	Exit
DVD DISP CLEAR	DVD Disp	DISC NAV LIST	List
CD MODE	CD Mode	APP MEDIA	Media
SUBTITLE	Subtitle	AD SUBT	Subt
AUDIO	Audio	SHIFT + SOUND DUAL	Shift + Dual
SYSTEM DISP	System Disp	DISPLAY INFO	Info
DISC 1	Disc 1	SHIFT + 1	Shift + 1
DISC 2	Disc 2	SHIFT + 2	Shift + 2
DISC 3	Disc 3	SHIFT + 3	Shift + 3
DISC 4	Disc 4	SHIFT + 4	Shift + 4
DISC 5	Disc 5	SHIFT + 5	Shift + 5
DISC SKIP	Disc Skip	D	Blue
OPEN/ CLOSE	Open/Close	ZOOM	Eject