Original	Replacement	Original	Replacement
Power TV- SAT	Power	9	9
Up	Up	0	0
Down	Down	Volume+ Tv	Vol +
Right	Right	Volume- Tv	Vol -
Left	Left	CH+ Tv Control	Ch +
Enter	Ok	CH- Tv Control	Ch -
Menu	Menu	TV/ SAT	Media
Guide	Guide	Front	Smart
Exit	Exit	Power Front	Shift + Power
1	1	Play Front	Play
2	2	>> Front	>>
3	3	<< Front	<<
4	4	Pause Front	Pause
5	5	Stop Front	Stop
6	6	Enter Down	3D
7	7	Input Select	AV
8	8	1 Front	Shift + 1

Original	Replacement	Original	Replacement
2 Front	SHIFT + 2 Shift + 2		
3 Front	SHIFT + 3 Shift + 3		
4 Front	SHIFT + 4 Shift + 4		
5 Front	SHIFT + 5 Shift + 5		
6 Front	SHIFT + 6 Shift + 6		
7 Front	SHIFT + 7 Shift + 7		
8 Front	SHIFT + 8 Shift + 8		
9 Front	SHIFT + 9 Shift + 9		
0 Front	SHIFT + 0 Shift + 0		
Channel + Front	SHIFT + CH + Shift + Ch +		
Channel - Front	SHIFT + CH – Shift + Ch -		

Original	Replacement	Original	Replacement
Power DVD	Power	Pause	Pause
Master	Vol +	Stop	Stop
Master Volume-	Vol -	>>I	>>I
Mute	Mute	1	1
Menu	Menu	2	2
Top Menu	Shift + Menu	3	3
Subtitle	Subt	4	4
Audio	Dual	5	5
Up	Up	6	6
Down	Down	7	7
Right	Right	8	8
Left	Left	9	9
Enter	Ok	0	0
Play	Play	· / +10	Pre Ch
<<	<<		
>>	>>		
I <<	I <<		

Original		Replacement	
SOURCE	Power FM-AM		Power
MASTER VOLUME +	Master	+ VOL	Vol +
− MASTER VOLUME	Master Volume-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TOP MENU P+	Display	DISPLAY INFO	Info
T.EDIT MENU	T. Edit	HOME SMART	Smart
SUBTITLE RF ATT GUIDE	RF ATT	APP MEDIA	Media
AUDIO EON P− EXIT	EON	DISC NAV LIST	List
TUNE +	Tune+	▲	Up
TUNE −	Tune-	▼	Down
ST+	ST+	▶	Right
ST−	ST-	◀	Left
ENTER	Enter	OK	Ok
D. ACCESS E	D. Access	D	Blue
MPX D	MPX	C	Yellow
CLASS C	Class	B	Green
SEARCH B	Search	SEARCH TV/R	TV/R

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
RECEIV	Power Receiver		Power
SIGNAL SELECT	Signal Select	HOME SMART	Smart
SOURCE	Power DVR-VCR	SHIFT +	Shift + Power
DVD	DVD	SHIFT + 1	Shift + 1
TV/SAT	TV/SAT	SHIFT + 5	Shift + 5
FRONT	Front	SHIFT + 4	Shift + 4
SLEEP	Sleep	PROG SLEEP	Sleep
DVR/VCR	DVR/VCR	SHIFT + 2	Shift + 2
FM/AM	FM/AM	SHIFT + 3	Shift + 3
DIMMER	Dimmer	APP MEDIA	Media
AUTO	Auto	E-MANUAL D.MENU	D. Menu
SURROUND	Surround	SOUND DUAL	Dual
ADVANCED	Advanced	AD SUBT	Subt
SOUND MODE	Sound Mode	PICTURE FORMAT	Format
SETUP	Setup	SETTINGS OPT	Options
TEST TONE	Test Tone	REPEAT TEXT	Text
CH.SELECT	CH. Select	ECO 3D	3D

Original		Replacement	
ROOM SETUP	Room Setup	A	Red
MUTE	Mute	MUTE	Mute
–	-	B	Green
+	+	C	Yellow
ENTER	Enter (Up)	SHIFT + FAV PRE-CH	Shift + Pre Ch
MASTER VOLUME –	Master Volume-	VOL –	Vol -
MASTER VOLUME +	Master	+ VOL	Vol +
TOP MENU P+	P+	+ CH	Ch +
TUNE +	Up/Tune+		Up
T.EDIT MENU	Menu	TOP MENU MENU	Menu
ST–	Left/ST-		Left
ENTER	Enter	OK	Ok
ST+	Right/ST+		Right
AUDIO EON P– EXIT	P-	CH –	Ch -
TUNE –	Down/Tune-		Down
SUBTITLE RF ATT GUIDE	Guide	-/-- GUIDE	Guide
EXIT	<<		<<

Original		Replacement	
	Pl ay	PLAY MODE	Pl ay
	>>/ A		>>
SEARCH B	I <</ B		I <<
CLASS C	Pause/ C		Pause
MPX D	St op/ D		St op
D.ACCESS E	>>I / E		>>I
1	1	1	1
2	2	2	2
3	3	3	3
ENTER	Ent er Down	TIMER AV	AV
4	4	4	4
5	5	5	5
6	6	6	6
+10	· / +10	FAV PRE-CH	Pr e Ch
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
CHANNEL +	Channel +	SHIFT + CH +	Shi f t + Ch +
CHANNEL −	Channel -	SHIFT + CH −	Shi f t + Ch -