Mandis shop

CU-XR013

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| POWER | Power | | Power | | |
| VOLU | Volume- | VOL − | Vol - | | |
| LUME + | Volume+ | + VOL | Vol + | | |
| FUNC | Func | HOME MENU | Menu / Home | | |
| TUN STA | Tuner Station- | TUNE- ◀◀ | << / Tune- | | |
| IER TION + | Tuner Station+ | TUNE+ ▶▶ | >> / Tune+ | | |
| S.BASS | S. Bass | LANG I/II AUDIO | Audio / Lang I/II | | |
| DISC | Disc | Prime Video RANDOM | Blue / Prime Video / Random | | |
| ■ | Stop | HOLD ■ | Stop / Hold | | |
| ❚❚ | Pause | STEP·FREEZE ❚❚ | Pause / Step / Freeze | | |
| ▶ | Play | SLOW ▶ | Play / Slow | | |
| PGM | PGM | OPT-TOOLS SETUP | Setup / OPT / | | |
| ⏮ | I<< | PRESET- ⏮ | I<< / Preset- | | |
| ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ | | |
| | | | | | |
| | | | | | |
| | | | | | |

https://al-remotecontrols.nl/en/Pioneer/16294-5B-replacement-remote-control-for-Pioneer-CU-XR013A001.htm