Original		Replacement	
	Standby		Power
	1	TV 1	1
	2	DVD 2	2
	3	CD - STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI - SAT 0	0
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Left		Left
	Right		Right
	I <<	PRESET-	I << / Preset -
	>>I	PRESET+	>>I / Preset +

Original		Replacement	
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow
PLAY/PAUSE	Play/Pause	STEP - FREEZE	Pause / Step / Freeze
RESUME	I >/ Resume	SHIFT + SLOW	Shift + Play /
SURROUND	Surround	SURROUND	Eject / Surround
SOUND	Sound	TITLE SOUND	Sound / Title
NIGHT	Night	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SUBW +	Subw +		Up
REAR +	Rear +	SHIFT + CH PAGE +	Shift + CH+ /
CENTER +	Center +	CH PAGE +	CH+ / Page+
TV VOL +	Tv Vol +	SHIFT + VOL +	Shift + Vol +
SUBW −	Subw -		Down

Original	Replacement	Original	Replacement
REAR Rear -	SHIFT + CH PAGE Shift + CH- /		
CENTER Center -	CH PAGE CH- / Page-		
TV VOL Tv Vol -	SHIFT + VOL Shift + Vol -		

Original		Replacement	
	Standby		Power
	1	TV 1	1
	2	DVD 2	2
	3	CD - STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
DISC DVD MENU	Disc (DVD	TOP MENU D.MENU	D. Menu / Top
	0	HDMI - SAT 0	0
VOL +	Vol +	VOL +	Vol +
DVD MENU SYSTEM	System (DVD	HOME MENU	Menu / Home
VOL −	Vol -	VOL −	Vol -
	I <<	PRESET-	I << / Preset -
	>>I	PRESET+	>>I / Preset +

Original		Replacement	
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play/ Pause	SLOW	Play / Slow
RESUME	I >/ Resume	SHIFT + SLOW	Shift + Play /

Original		Replacement	
	Standby		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down

Original	Replacement

Original		Replacement		Original	Replacement
	St andby		Power		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		