Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
DUAL I-II	I-II / Dual	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
P.SIZE	P. Size	SIZE ZOOM	Zoom / Size
TV/DTV	Tv/DTV	PROGRAM TV/RADIO	TV/Radio /
D.MENU	D. Menu	TOP MENU D.MENU	D. Menu / Top
PIP	PIP	OPT-TOOLS SETUP	Setup / OPT /
TEXT/MIX	Text/MIX	GOTO TEXT	Text / Goto
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement	
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER /OK	Enter/OK	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
PRE-CH	PRE-CH	RETURN BACK	Back / Return
	Vol +	VOL +	Vol +
CH LIST	CH. List	LIST SMART	Smart / List
P	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
	P-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Replacement		Original	Replacement
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
STILL	Still	SHIFT + STEP - FREEZE II	Shift + Pause / Step /		
SRS	SRS	SHIFT + TOP MENU D.MENU	Shift + D. Menu / Top Menu		
RETURN	Return	SHIFT + RETURN BACK	Shift + Back / Return		
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0		

Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER /OK	Enter / OK	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -

Original		Replacement	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Replacement	
POWER	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
REW	<<	TUNE-	<< / Tune-
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
FF	>>	TUNE+	>> / Tune+
	Vol +	VOL +	Vol +

Original		Replacement	
P	P+	CH PAGE +	CH+ / Page+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol -	VOL −	Vol -
	P-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
ENTER /OK	Enter / OK	OK	OK
	Right		Right
	Down		Down
INFO	Info	ANGLE INFO	Info / Angle

Original	Replacement
Cable	Display / Media
Power	Power
Power Cable	Shift + Power
Source	AV / Input / RDS
1	1
1 Cable	Shift + 1
2	2
2 Cable	Shift + 2
3	3
3 Cable	Shift + 3
4	4
4 Cable	Shift + 4
5	5
5 Cable	Shift + 5
6	6
6 Cable	Shift + 6
7	7

Original	Replacement
7 Cable	Shift + 7
8	8
8 Cable	Shift + 8
9	9
9 Cable	Shift + 9
0	0
0 Cable	Fav / Marker / PC
PRE-CH	Back / Return
D. Menu	D. Menu / Top
HDMI	Shift + 0
<<	<< / Tune-
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
>>	>> / Tune+
Vol +	Vol +
P+	CH+ / Page+

Original	Replacement	Original	Replacement
P+ Cable	SHIFT + CH PAGE +	Shift + CH+ /	
MUTE	DIMMER MUTE	Mute / Dimmer	
Vol -	VOL −	Vol -	
P-	CH PAGE −	CH- / Page-	
P- Cable	SHIFT + CH PAGE −	Shift + CH- /	
MENU	HOME MENU	Menu / Home	
EXIT	CLEAR EXIT CANCEL	Exit / Cancel / Clear	
Up	Up	Up	
Left	Left	Left	
ENTER /OK	OK	OK	
Right	Right	Right	
Down	Down	Down	
INFO	ANGLE INFO	Info / Angle	
P.SIZE	SIZE ZOOM	Zoom / Size	
GUIDE	-/-- GUIDE EPG	Guide / EPG / -/--	