Mandis shop

BN59- 01223A

Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
SPORTS	Sports	APP MEDIA	Media
SEARCH	Search	SEARCH TV/R	TV/R
EXTRA	Extra	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
–	--	SHIFT + -/-- GUIDE	Shift + Guide
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch

Original		Replacement	
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
CH	CH+	+ CH	Ch +
CH	CH-	CH –	Ch -
CH LIST	CH List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
TOOLS	Tools	SETTINGS OPT	Options
SMART HUB	Smart Hub	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left

Original		Replacement	
	Enter	OK	Ok
A	Red	A	Red
B	Green	B	Green
C	Yellow	C	Yellow
D	Blue	D	Blue
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu
CC	CC	AD SUBT	Subt
MTS	MTS	ECO 3D	3D
PIC SIZE	Pic Size	ZOOM	Eject
PICTURE	Picture	PICTURE FORMAT	Format
SOUND	Sound	SOUND DUAL	Dual
<<	<<	<<	<<
II	Pause	II	Pause
>>	>>	>>	>>
>>I	>>I	>>I	>>I
I<<	I<<	I<<	I<<
	Rec	REC MODE	Rec

Original		Replacement	
	Play	PLAY MODE	Play
	Stop		Stop