| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| SOURCE | Source | TIMER AV | AV |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| TTX/MIX | TTX/MIX | REPEAT TEXT | Text |
| PRE-CH | PRE-CH | FAV PRE-CH | Pre Ch |
| + | Vol + | + VOL | Vol + |
| — | Vol - | VOL — | Vol - |
| MUTE | Mute | MUTE | Mute |

| Original | | Replacement | |
|---|---|---|---|
| CH LIST | CH List | DISC NAV LIST | List |
| P | P+ | + CH | Ch + |
| P | P- | CH — | Ch - |
| CONTENT | Content | SHIFT + SETTINGS OPT | Shift + Options |
| MENU | Menu | TOP MENU MENU | Menu |
| GUIDE | Guide | -/-- GUIDE | Guide |
| TOOLS | Tools | SETTINGS OPT | Options |
| INFO | Info | DISPLAY INFO | Info |
| ▲ | Up | ▲ | Up |
| ◀ | Left | ◀ | Left |
| OK | Enter | OK | Ok |
| ▶ | Right | ▶ | Right |
| ▼ | Down | ▼ | Down |
| RETURN BACK | Return | RETURN BACK | Back |
| EXIT | Exit | CLEAR EXIT | Exit |
| A | Red | A | Red |
| B | Green | B | Green |

| Original | | Replacement | |
|---|---|---|---|
| C | Yellow | C | Yellow |
| D | Blue | D | Blue |
| MEDIA.P | Media. P | APP MEDIA | Media |
| INTERNET @TV | Internet @TV | HOME SMART | Smart |
| 3D | 3D | ECO 3D | 3D |
| D | D | E-MANUAL D.MENU | D. Menu |
| P.SIZE | P. Size | PICTURE FORMAT | Format |
| SUBT. | Subt. | AD SUBT | Subt |
| << | << | << | << |
| Pause | Pause | Pause | Pause |
| >> | >> | >> | >> |
| Rec | Rec | REC MODE | Rec |
| Play | Play | PLAY MODE | Play |
| Stop | Stop | Stop | Stop |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |