Mandis shop

Samsung BP5900139A

Original		Replacement	
ON	On		Power
AUTO	Auto	DVD 2	2
OFF	Off	SHIFT +	Shift + Power
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
	Up		Up
	Left		Left
	Enter	OK	OK
	Right		Right
	Down		Down
V.KEY-STONE +	V. Keystone+	CH PAGE +	CH+ / Page+
BLANK	Blank	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
V.KEY-STONE −	V. Keystone-	CH PAGE −	CH- / Page-
STILL	Still	STEP-FREEZE	Pause / Step / Freeze
VIDEO	Video	VIDEO 4	4
COMP	Comp	TV 1	1

Original		Replacement	
HDMI	HDMI	HDMI - SAT 0	0
S-VIDEO	S-Video	TAPE 5	5
PC	PC	PC FAV MARKER	Fav / Marker / PC
INSTALL	Install	TOP MENU D.MENU	D. Menu / Top
P.SIZE	P. Size	SIZE ZOOM	Zoom / Size
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format

https://al-remotecontrols.nl/en/Samsung/1065-326-replacement-remote-control-for-Samsung-TV-BP59-00139A.html