Mandis shop

Sharp RRMCG0150AWSA

Original		Replacement		Original	Replacement
	Stop		Stop / Hold		
	Play		Play / Slow		
	Disc Skip		Display / Media		
	<</ Preset		I<< / Preset-		
	>>/ Preset Up		>>I / Preset+		
	Pause		Pause / Step / Freeze		
	Memory		OK		
	Clear		Exit / Cancel / Clear		
	X-Bass		Audio / Lang I/II		
	CD		3		
	Tuner (Band)		6		
	Tape		5		
	On/Standby		Power		
	Vol -		Vol -		
	Vol +		Vol +		

https://al-remotecontrols.nl/en/Sharp/1061825-replacement-remote-control-for-Sharp-RRMCG0150AWSA.htm